

COST BOOK #	PWR GEAR SYSTEM #	PWR GEAR PART #	FLTWD PART #	DESCRIPTION
N91-1195	908394001			STRAP BATTERY
L85-0020		<u>1010000060</u>	<u>521405</u>	EMERGENCY RETRACTING MODULE
L10-9025		<u>1010000140</u>	505297	JACK- ELECT LVLR15 LH 9K (REAR)
L10-9024		<u>1010000051</u>	505296	JACK, ELEC. 9K RH REAR 15" STROKE
L10-9021		<u>1010000056</u>	<u>520857</u>	BRACKET, WELD ELECTRIC JACK KIT
L10-9021		<u>1010000139</u>	505295	JACK- ELECT LVLR LH 9K JACK, 13" STROKE - ROADSIDE (FRONT/REAR)
I10-9021	<u>1010000139</u>	1010001889	568909	jack leg pin kit
L10-9020		<u>501473</u>	505294	JACK - ELECT LVLR RH 9K 13" CURBSIDE (FRONT/REAR)
L10-9020	<u>501473 (JACK)</u>	<u>1010001066</u>	*1*	BRACKET WELD ELECT LEV FLM GAS
L10-9020		180-1098		grooved pin .25 od x 2.25
L10-8023	<u>9010000306</u>	<u>1010001066</u>	*1*	BRACKET WELD ELECT LEV FLM GAS
L10-8023	<u>9010000306</u>	140-1244	<u>533066</u>	SENSOR FOR ALL ELECTRIC JACKS
L10-8023	<u>9010000306</u>	141-0050384	536934	HARNESS (141-0050RR384)
L10-8023	<u>9010000306</u>	<u>1010000141</u>	514796	9K 13" STROKE FRONT LH ASSY ELEC JACK - FRONT DRIVER SIDE LEFT FRONT
L10-8023	<u>9010000306</u>	1010000142	514060	9K 13" STROKE FRONT RH ASSY ELEC JACK - FRONT PASSENGER RIGHT FRONT
L10-8023	<u>9010000306</u>	<u>1010001066</u>		jack bracket
L10-8023	<u>9010000306</u>	1202015		bolts for jacks
L10-8023	<u>9010000306</u>	16.1030		Washers for jacks
L10-8023	<u>9010000306</u>	15-1346		nuts for jacks
L10-8023	<u>9010000306</u>	140-1226	<u>407218</u>	touchpad
L10-8022	<u>9010000028</u>	<u>1010000141</u>	514796	9K 13" STROKE FRONT LH ASSY ELEC JACK - FRONT DRIVER SIDE LEFT FRONT
L10-8022	140-1224	<u>1010000141</u>		HARNESS, CONTROL BOX TO MOTOR & SENSORS - LONGER THAN 141-0047200 THIS IS 384"

L10-8022	<u>9010000028</u>	1010000142	514060	9K 13" STROKE FRONT RH ASSY ELEC JACK - FRONT PASSENGER RIGHT FRONT
L10-8022	<u>9010000028</u>	<u>1010000143</u>	514059	12K 13" STROKE REAR LH ASSY ELEC JACK - REAR DRIVER SIDE REAR LEFT
L10-8022	<u>9010000028</u>	1010000144	514797	12K 13" STROKE REAR RH ASSY ELEC JACK - REAR PASSENGER REAR RIGHT
L10-8022	<u>9010000028</u>	<u>990-1115</u>	<u>539203</u>	MAGNET FOR JACK SENSOR
L10-8022	140-1224	1510000032		SAFTEY INTERCONNECT HARNESS
L10-8022	<u>9010000028</u>	140-1224	<u>548838</u>	CONTROLLER
L10-8022	<u>9010000028</u>	140-1226	<u>407218</u>	TOUCH PAD ONLY
L10-8022	<u>9010000028</u>	140-1244	<u>533066</u>	SENSOR FOR JACK
L10-8022	140-1224	141-0045420		TOUCHPAD to CONTROL BOX HARNESS
L10-8022	<u>9010000028</u>	141-0046010	<u>525383</u>	HARNESS, SENSOR FOR CONTROL BOX
L10-8022	140-1224	141-0046010	<u>525383</u>	SENSOR HARNESS FOR CONTROL BOX
L10-8022	140-1224	141-0047200		HARNESS, CONTROL BOX TO MOTOR & SENSORS 200" (16.6FT)
L10-8022	<u>9010000028</u>	500091		NUTS AND BOLTS & WASHER FOR ELECTRIC JACK - 6 OF EACH PER JACK
L10-8022	<u>9010000028</u>	800336	505290	CONTAINS 4 HARNESSES 141-0047LF200, 141-0047RF200, 141-0050LR384, AND 141-0050RR384
L10-8022	<u>9010000028</u>	<u>990-1115</u>	<u>539203</u>	MAGNET
L10-8022	<u>9010000028</u>			LEVELER KIT ELEC
L10-8022	<u>9010000028</u>	<u>1010001289</u>	<u>549107</u>	brake for jacks
L10-8020	<u>9010000003</u>	140-1224	<u>548838</u>	CONTROLLER
L10-8020	<u>9010000003</u>			LEVELER KIT ELEC FORD
L10-8018	<u>9010000058</u>	140-1224	<u>548838</u>	CONTROL BOX
L10-8018	<u>9010000058</u>			LEVELER KIT ELEC WORKHOUSE
L10-8018	<u>9010000058</u>	140-1226	<u>407218</u>	TOUCH PAD
L10-5098	500127	500145	088507	JACKS (ALL 3 THE SAME)

L10-5098	500145	800131S	376084	SEAL KIT
L10-5096	500137	500094	074794	SPRING KIT
L10-5096	500137	500310	<u>507544</u>	SOLENOID
L10-5093	500517	500146	073677	9K JACK 15" STROKE
L10-5093	500517	500235H		9K JACK 12" STROKE
L10-5093	500517			LEVELING SYSTEM
L10-5092	500214			
L10-5092	500214	500097	<u>112837</u>	dump valve
L10-5091	500102	500104		PUMP - NO LONGER AVAIL. CALL PG FOR SUB
L10-5091	500102	500145	088507	JACK ASSY (ALL 3 SAME)
L10-5091	500102	500299	137200	FLOAT SWITCH
L10-5090	500087	500082	073677	500082 NOW REPLACED BY 500146 - ALL 3 JACKS IN SYSTEM ARE THE SAME
L10-5090	500087		063956	JACK, LEVELER 3 PT MANUAL
L10-5090	500087	<u>1010001131</u>	<u>538366</u>	TOUCHPAD/CONTROLLER KIT W/HARNESSES
L10-5090	500087	800129S	<u>407220</u>	SEAL KIT FOR JACKS
L10-5089	500213	500118	<u>076108</u>	FLOAT SWITCH ASSY w/ grommet
L10-5089	500213	500082	073677	JACK (ALL 3 SAME)
L10-5089	500213	800129S	<u>407220</u>	SEAL KIT
L10-5089	500213	800038s		TANK REPLACEMENT KIT
L10-5089	500213	<u>1010001131</u>	<u>538366</u>	TOUCHPAD/CONTROLLER KIT W/HARNESSES
L10-5089	500213	500210		TOUCH PAD
L10-5089	500213	500094	074794	Spring assy only
I10-5089	500213	500543		pump assy
L10-2300	500638	500199	<u>086594</u>	FLOAT SWITCH
L10-2300	500638	800301	<u>475030</u>	pump assy only
L10-2300	500638	13-1104		motor pump assy
L10-2300	500638	500145	088507	JACK (ALL 3 SAME)
I10-2300	500638	800036s		TANK REPLACEMENT KIT
I10-2195	<u>9010000554</u>	080-aa408ws		35' x 1/4 d hydraulic hose
I10-2195	<u>9010000554</u>	500759	407225	front jack.
I10-2195	<u>9010000554</u>	1010002017		hose kit
I10-2195	<u>9010000554</u>	500800	445092	rear jack
I10-2300	<u>9010000447</u>	501173		R/S FRONT JACK
I10-2301	500768	500620		rear jack
I10-2194	<u>9010000447</u>	1510000070		hydraulic fluid level sensor/float switch
I10-2194	<u>9010000447</u>	501173		front jack
I10-2194	<u>9010000447</u>	1010001284	<u>574052</u>	control box

I10-2194	<u>9010000447</u>	140-1226	<u>407218</u>	touch pad
I10-2194	<u>9010000447</u>	3510000109		PUMP/MOTOR ASSY
I10-2194	<u>9010000447</u>	500833	407222	rear jack
I10-2193	<u>9010000448</u>	500832	407223	front jack
I10-2193	<u>9010000448</u>	1510000070		fluid sensor/switch
I10-2193	<u>9010000448</u>	500833	407222	rear jack
I10-2193	<u>9010000448</u>	1010001578		hose kit
I10-2193	<u>9010000448</u>	3510000109		PUMP/MOTOR ASSY
L10-2192	<u>9010000425</u>	3510000111	565645	rear jack
L10-2192	<u>9010000425</u>	141-0045420		harness, control box
L10-2192	<u>9010000425</u>	10100001284		control box assy
L10-2192	<u>9010000425</u>	140-1226	<u>407218</u>	TOUCH PAD
L10-2192	<u>9010000425</u>	500568		dump valve
L10-2192	<u>9010000425</u>	500833	407222	front jack
L10-2192	<u>9010000425</u>	<u>1010001487</u>		hose kit
L10-2191	<u>9010000424</u>	<u>500932</u>	472731	LEFT FRONT JACK ASSY
L10-2191	<u>9010000424</u>	3510000111	565645	rear jack
L10-2191	<u>9010000424</u>	800129S	<u>407220</u>	SEAL KIT FOR 500146 JACKS FRONT/REAR
L10-2191	<u>9010000424</u>	140-1226	<u>407218</u>	touchpad
L10-2191	<u>9010000424</u>	10100001284		controller
L10-2191	<u>9010000424</u>	080-aa024ws		pass rear hose
L10-2191	<u>9010000424</u>	141-0045420		touchpad/control box harness
L10-2191	<u>9010000424</u>	1510000065		pump/control harness
L10-2191	<u>9010000424</u>	3010001126		cap for jack pump
L10-2191	<u>9010000424</u>	030-1040	<u>497545</u>	grommet for jack pump
L10-2190	<u>9010000380</u>	500310	<u>507544</u>	SOLENOID ONLY
L10-2190	<u>9010000380</u>	500759	407225	FRONT JACK (RIGHT OR LEFT)
L10-2190	<u>9010000380</u>	500450	<u>350114</u>	FLOAT SWITCH
L10-2190	<u>9010000380</u>	500800	445092	REAR JACK (either right or left)
L10-2190	<u>9010000380</u>	10100001284		jack controller
L10-2190	<u>9010000380</u>	3510000162		pump (w/manifold)
L10-2190	<u>9010000380</u>	3510000146		Pump w/o Manifold
L10-2190	<u>9010000380</u>	540173		lock valve
L10-2190	<u>9010000380</u>	540172		cyl assy w/lock valve
L10-2190	<u>9010000380</u>	540145		cylinder only
L10-2190	<u>9010000380</u>	500439	<u>309222</u>	leg valve solenoid
L10-2183	<u>500944</u>	500933		FRONT JACK (RIGHT OR LEFT)
L10-2183	<u>500944</u>	140-1226	<u>407218</u>	TOUCH PAD
L10-2183	<u>500944</u>	140-1227	<u>479221</u>	CONTROL BOX
L10-2182	<u>500900</u>	500629S	<u>407218</u>	touchpad
L10-2182	<u>500900</u>	500832	407223	FRONT JACKS (BOTH)
L10-2182	<u>500900</u>	500833	407222	REAR JACKS (BOTH)

L10-2182	<u>500900</u>	080-aa219-ii		219" hose
L10-2182	<u>500900</u>	080-aa264-ii		264" hose
L10-2181	500903	500097	<u>112837</u>	SOLENOID/ DUMP VALVE
L10-2181	500842	500590	515803	SPRING KIT FOR 500842 (FRONT JACK)
L10-2181		500590	515803	SPRING KIT FOR 500842
L10-2181	500903	500833	407222	REAR JACK
L10-2181	500903	500842	407221	FRONT JACK
L10-2181	500842	800133S	407334	SEAL KIT
L10-2181	500833	800138S	<u>407335</u>	SEAL KIT
L10-2181	500903			TOUCH PAD
L10-2180	500899	500843		REAR JACK
L10-2180	500899	500876		FRONT JACK
L10-2180	500899	<u>500893</u>	456945	PUMP ASSY
L10-2179	500507	500091		KIT, BOLTS, WASHERS AND NUTS FOR JACK # 500800
L10-2179	500800	500091		KIT, 6 BOLTS(15-1035) , 6 WASHERS (16-1030) and 6 NUTS (15-1109)
L10-2179	<u>500824</u>	500097	<u>112837</u>	DUMP VALVE FOR JACK
L10-2179	<u>500824</u>	500099	<u>084178</u>	LEG VALVE FOR JACK
L10-2179	<u>500824</u>	500199	86594	FLOAT SWITCH/SENSOR
L10-2179	<u>500824</u>	500310	<u>507544</u>	SOLENOID ONLY
L10-2179	<u>500893</u>	500523		O-RING KIT FOR JACK MANIFOLD
L10-2179	<u>500824</u>	500759	407225	FRONT JACK
L10-2179		500759	<u>407335</u>	SEAL KIT FOR 500759
L10-2179	<u>500824</u>	500800	445092	REAR JACK (either right or left)
L10-2179	<u>500824D</u>	500800	224116	REPLACE WITH 500385TH ON '06 PROVIDENCE & /REVOLUTIONS
L10-2179	<u>500824</u>	<u>500893</u>	456945	PUMP ASSY COMPLETE (PWR UNIT)
L10-2179	<u>500824D</u>	<u>501102 sub to 500893</u>	456945	PUMP/MOTOR ASSY
L10-2179	<u>500824</u>	800301	<u>475030</u>	PUMP ONLY
L10-2179	<u>500824</u>	030-1071		seal that goes with 800301
L10-2179	500507	800302	<u>497544</u>	PUMP ASSY MOTOR ONLY
L10-2179	<u>500824(D)</u>	800302	<u>497544</u>	MOTOR ONLY FOR PUMP ASSY
L10-2179	<u>500824D</u>	030-1040	<u>497545</u>	RUBBER GROMMET
L10-2179	<u>500824D</u>	030-1040	<u>497545</u>	RUBBER GROMMET
L10-2179		07-1238		FILL PLUG (SCREW IN BRASS W/ ORING)

L10-2179	<u>500824</u>	07-1239		DRAIN PLUG FOR RESERVOIR (NOT A DIPSTICK)
L10-2179	<u>500824D</u>	07-1239		HEXAGON SHAPED PLUG (TO DRAIN) TANK
L10-2179	<u>500824D</u>	130-1213	<u>507545</u>	BREATHER CAP W/ DIPSTICK
L10-2179	<u>500824D</u>	130-1214	527463	PUSH IN - FILL CAP (WITH DIPSTICK) PLASTIC - NO THREADS
L10-2179	<u>500824</u>	13-1100	248867	MOTOR& PUMP ONLY ASSY P/OF 500893
L10-2179	<u>500824</u>	140-1227	<u>479221</u>	CONTROL BOX ONLY
L10-2179	<u>500824</u>	500629S	<u>407218</u>	TOUCH PAD
L10-2179		800036S		TANK REPLCEMENT KIT
L10-2179	<u>500824</u>			ELBOW CONNECTOR INTO JACK
L10-2179	<u>500824</u>			INLINE FITTING INTO JACK
L10-2179	<u>500824</u>	080-aa076-ll	466373	76" HOSE
L10-2179	<u>500824</u>	080-aa106-ll	390780	106" HOSE
L10-2179	<u>500824</u>	080-aa287-ll	514063	287" HOSE
L10-2179	<u>500824</u>	080-aa306-ll	514062	306" HOSE
L10-2177	500846	500235H		REAR JACK
L10-2177	500846	500252	100307	spring kit for jack 500235
L10-2177	500846	500590	515803	spring kit for jack 500384
L10-2176	500802	500099	<u>084178</u>	SOLENOID
L10-2176	500802	500199	86594	FLOAT SWITCH/SENSOR
L10-2176	500802	500457	<u>138334</u>	LEVEL CONTROL BOX
L10-2176	500802	500634	<u>084178</u>	SOLENOID
L10-2176	500802	500759	407225	FRONT JACK (BOTH)
L10-2176	500802	080-AA076-ii	466373	76" HOSE
L10-2176	500802	500097	<u>112837</u>	DUMP VALVE
L10-2176	500802	080-AA106-ii	390780	106" HOSE
L10-2176	500802	080-AA287-ii	514063	287" HOSE
L10-2176	500802	080-AA306-ii	514062	306" HOSE
L10-2176	500802	<u>500455R2</u>	137199	LEVELER KIT - CONTROL PANEL, CONTROL BOX # 500457, AND HARNESS
L10-2176	500802	500800	445092	REAR JACK (BOTH)
L10-2176	500802	3510000159		complete pump assy
L10-2175	<u>500801</u>	500199	<u>086594</u>	FLOAT SWITCH/LEVEL SENSOR
L10-2175	<u>500801</u>	500759	407225	REAR JACK
L10-2175	<u>500801</u>	500335		PUMP WIRE HARNESS
L10-2175	<u>500801</u>	500491	<u>460714</u>	HARNESS
L10-2175	<u>500801</u>	500730	407226	FRONT JACK
L10-2175	<u>500801</u>	5014-209		

L10-2175	<u>500801</u>	080-AA264-II		HYDRAULIC HOSE
L10-2175	<u>500801</u>	800302	<u>497544</u>	MOTOR ONLY FOR PUMP ASSY
L10-2174	<u>500689</u>	500146	073677	REAR JACK
L10-2174	<u>500689</u>	08-A326		HOSE F 6 J 326
L10-2174	<u>500689</u>	<u>500384HR</u>	364626	FRONT JACK
L10-2173	500671	500094	074794	spring kit for jack 500082
L10-2173	500671	500590	515803	SPRING KIT FOR JACK 500384
L10-2172	500606	500456	*2*	CONTROL PANEL
L10-2172	500606	500457	<u>138334</u>	CONTROL BOX
L10-2172	500606	500491	<u>460714</u>	HARNESS FOR CONTROL BOX/PANEL
L10-2172	500606	800036s		TANK REPLACEMENT KIT
L10-2172	500606	500590	515803	SPRING KIT
L10-2172	500606	<u>500455R2</u>	137199	LEVELER KIT - CONTROL PANEL, BOX, AND HARNESS
L71-2172	500606	501022	364626	FRONT JACK(500384HR + fittings)
L71-2172	500606	800302	<u>497544</u>	MOTOR ONLY FOR PUMP ASSY
L71-2172	500606	500146	073677	rear jack
L10-2171	<u>500626</u>	<u>500384HR</u>	364626	6K JACKS FRONT
L10-2171	<u>500626</u>	500385TH	224116	12K JACKS REAR
L10-2171	<u>500626</u>			LEVELING SYSTEM
L10-2152	500411	500199	<u>086594</u>	FLOAT SWITCH/ SENSOR
L10-2152	500411	800301	<u>475030</u>	PUMP ONLY
L10-2152	500411	800302	<u>497544</u>	MOTOR ONLY FOR PUMP ASSY
L10-2152	500411	500099	<u>084178</u>	leg valve coil
L10-2152	500411	500097	<u>112837</u>	dump valve coil
L10-2152	500411	13-1100	248867	PUMP & MOTOR ASSY
L10-2152	500411	500094	074794	SPRING ASSY ONLY
L10-2152	500411	500385TH	224116	REAR JACK
L10-2152	500411			TANK REPLACEMENT KIT
L10-2152	500411	800137S	407333	SEAL KIT
L10-2152	500411	500097	<u>112837</u>	DUMP VALVE W/ SOLENOID KIT
L10-2152	500411	<u>1010001131</u>	<u>538366</u>	control kit
L10-2151	500410	500146	073677	REAR JACK
L10-2151	500410	500199	<u>086594</u>	FLOAT SWITCH/SENSOR
L10-2151	<u>500384HR</u>	501022	364626	FRONT JACK(500384HR + fittings)
L10-2151	500410	500590	515803	jack spring for front jack 500384
L10-2151	500410	500082H	073677	REAR JACK
L10-2151	500410	08-A264		REAR HOSE

L10-2151	500410	800036s		TANK REPLCEMENT KIT
L10-2151	500410	500487		hydraulic hose kit
L10-2151	500410	800036s		hydraulic fluid reservoir
L10-2151	500410	3510000159		manifold and pump
L10-2150	500409	500235H		REAR JACKS 9K (SHORTY)
L10-2150	500409	500482H		FRONT JACKS 6K (SHORTY)
L10-2150	500409	500252	100307	SPRING KIT
L10-2110	500890	500145	088507	JACK (ALL 3 SAME)
L10-2110	500890	140-1226	<u>407218</u>	touch pad
L10-2110	500890	140-1227	<u>479221</u>	control box
L10-2100	500301			LEVELING SYSTEM
L10-2100	500301	500145	088507	JACK (ALL 3 SAME)
L10-2090	<u>9010000181</u>	090-1170	541384	DIRECTIONAL VALVE
L10-2090	<u>9010000181</u>	501175		FOOT PAD ONLY FOR JACK
L10-2090	<u>9010000181</u>	501234	480907	PUMP ASSY COMPLETE/ POWER UNIT VERT 1.4 GAL
L10-2090	<u>9010000181</u>	09-1141		solenoid only
L10-2090	<u>9010000181</u>		514203	LVLR-HYD SYS 4PT AUTO(TAG)/PWR
L10-2090	<u>9010000181</u>	140-1226	<u>407218</u>	TOUCH PAD
L10-2090	<u>9010000181</u>	140-1229	<u>521634</u>	CONTROL BOX
L10-2090	<u>9010000181</u>	080-AA470WSTCF	500785	470" HOSE TOP CURBSIDE FRONT
L10-2090	<u>501234</u>	3510000147	<u>512328</u>	PUMP& MOTOR ASSY ONLY
L10-2090	<u>501234</u>	500310	<u>507544</u>	solenoid only for pump
L10-2090	<u>9010000181</u>	501095	527769	FRONT JACK -SEE COMMENTS
L10-2090	<u>9010000181</u>	501175		foot pad for jack 501095
L10-2090	<u>9010000181</u>	501096	478158	REAR JACK- SEE COMMENTS
L10-2090	<u>9010000181</u>	501175		foot pad for jack 501096
L10-2090	<u>9010000181</u>	1010000947	551093	HOSE KIT - CONTAINING 470" (QTY4) AND 144" (QTY 4) - 8 HOSES TOTAL
L10-2090	<u>9010000181</u>	090-1168	<u>533830</u>	PRESSURE SWITCH
L10-2076	<u>501205</u>	500310	<u>507544</u>	SOLENOID KIT
L10-2076	<u>501205</u>	501095	527769	FRONT JACK -SEE COMMENTS
L10-2076	<u>501205</u>	501175		foot pad for jack 501095
L10-2076	<u>501205</u>	501096	478158	REAR JACK- SEE COMMENTS
L10-2076	<u>501205</u>	501175		foot pad for jack 501096

L10-2076	<u>501205</u>	501234	480907	PUMP ASSY COMPLETE/ POWER UNIT VERT 1.4 GAL
L10-2076	<u>501205</u>	1010000948		HOSE KIT - CONTAINING 410" (QTY4) AND 144" (QTY 4) - 8 HOSES TOTAL
L10-2076		080-AA144WSBCR	500780	144" HOSE BOTTOM CURB REAR
L10-2076		080-AA144WSBRR	500781	144" HOSE BOTTOM R/S REAR
L10-2076		080-AA144WSTCR	500782	144" HOSE TOP CURB REAR
L10-2076		080-AA144WSTRR	500783	144" HOSE TOP R/S REAR
L10-2076		080-AA410WSBCF	508182	410" HOSE BOTTOM CURB FRONT
L10-2076		080-AA410WSBRF	508184	410" HOSE BOTTOM R/S FRONT
L10-2076		080-AA410WSTCF	508183	410" HOSE TOP CURB FRONT
L10-2076		080-AA410WSTRF	508181	410" HOSE TOP R/S FRONT
L10-2076	<u>501205</u>	090-1168	<u>533830</u>	PRESSURE SWITCH
L10-2076		090-1170	541384	DIRECTIONAL VALVE
L10-2076	<u>501234</u>	130-1213	507545	BREATHER CAP W/ DIPSTICK (PUSH IN FILL CAP)
L10-2076	<u>501234</u>	3510000147	<u>512328</u>	PUMP& MOTOR ASSY ONLY
L10-2076	<u>501205</u>	140-1226	<u>407218</u>	TOUCH PAD
L10-2076	<u>501205</u>	140-1229	<u>521634</u>	CONTROL BOX (NO HARNES)
L10-2076	<u>501205</u>	141-0044420		HARNES FROM TOUCHPAD TO CONTROL BOX.
L10-2076	<u>501205</u>			HOSE KIT - ALL 410" (4 HOSES EACH)
L10-2076	<u>501205</u>			HOSE KIT - ALL 144" (4 HOSES EACH)
L10-2075	<u>501179</u>	501186		REAR MANIFOLD ASSY
L10-2075	<u>501179</u>	080-AA144WSBCR	500780	144" HOSE BOTTOM CURBSIDE REAR
L10-2075	<u>501179</u>	080-AA144WSBRR	500781	144" HOSE BOTTOM ROADSIDE REAR
L10-2075	<u>501179</u>	080-AA144WSTCR	500782	144" HOSE TOP CURBSIDE REAR
L10-2075	<u>501179</u>	080-AA144WSTRR	500783	144" HOSE TOP ROADSIDE REAR
L10-2075	<u>501179</u>	080-AA470WSBCF	490564	470" HOSE BOTTOM CURBSIDE FRONT

L10-2075	<u>501179</u>	080-AA470WSBRF	490546	470" HOSE BOTTOM ROADSIDE FRONT
L10-2075	<u>501179</u>	080-AA470WSTCF	500785	470" HOSE TOP CURBSIDE FRONT
L10-2075	<u>501179</u>	080-AA470WSTRF	500786	470 " HOSE TOP ROADSIDE FRONT
L10-2075	<u>501179</u>	1010000947	551093	HOSE KIT - CONTAINING 470" (QTY4) AND 144" (QTY 4) - 8 HOSES TOTAL
L10-2075	<u>501179</u>	140-1194	<u>464734</u>	CONTROLLER
L10-2075	<u>501179</u>	501095	527769	FRONT JACKS (BOTH)
L10-2075	<u>501179</u>	501175		foot pad for jack 501095
L10-2075	<u>501179</u>	501096	478158	REAR JACKS (BOTH)
L10-2075	<u>501179</u>	501175		foot pad for jack 501096
L10-2075	<u>501179</u>			LEVELER HYDRAULIC SYSTEM 4PT AUTO
L10-2075	<u>501090</u>	501090		PUMP ASSY/ HYDRAULIC POWER UNIT FOR 501179
L10-2075	<u>501179</u>	3510000147	<u>512328</u>	PUMP MOTOR AND RESERVIOR TANK PART OF 501090 - CANNOT GET COMPONENTS OF THIS.
L10-2075	<u>501179</u>	090-1161		check valve
L10-2075	<u>501179</u>	500439		leg valve replacement
L10-2075	<u>501179</u>	090-1170	541384	DIRECTIONAL VALVE
L10-2075	<u>501179</u>	09-1141		coil for directional valve
L10-2073	<u>501178</u>	500310	<u>507544</u>	MOTOR START SOLENOID
L10-2073	<u>501178</u>	501095	527769	FRONT JACK (BOTH SAME) 10K JACK, 18" BORE, 3" STROKE ASSY 10K
L10-2073	<u>501178</u>	501175		foot pad for jack 501095
L10-2073	<u>501178</u>	501096	478158	REAR JACK (BOTH SAME) 17K
L10-2073	501095	501175		FOOT PAD ONLY FOR JACK
L10-2073	501096	501175		FOOT PAD ONLY FOR JACK
L10-2073	<u>501178</u>	501182	<u>537662</u>	PRESSURE SENSOR SWITCH (air)
L10-2073	<u>501178</u>	501186		REAR MANIFOLD ASSY
L10-2073	<u>501178</u>	501187		FRONT MANIFOLD ASSY

L10-2073	<u>501178</u>	800281		QTY 2 140-1190 TERMINATING RECEPTICAL, QTY 1 PN 140-1191 SENSOR, LEVELING FRONT AIR, QTY 1 140-1192 SENSOR, LEVELING, REAR HYD, QTY 1 141-0017 WIRE HARNESS
L10-2073	<u>501178</u>	080-AA120-WSBCR	490532	120 "HOSE-CURBSIDE- REAR
L10-2073	<u>501178</u>	080-AA120-WSBRR	490565	120" HOSE - ROADSIDE - REAR
L10-2073	<u>501178</u>	080-AA470WSBCF	490564	470" HOSE- CURBSIDE FRONT
L10-2073	<u>501178</u>	080-AA470WSBRF	490546	470" HOSE- ROADSIDE FRONT
L10-2073	<u>501178</u>	090-1160	*1*	PRESSURE RELIEF VALVE
L10-2073	<u>501178</u>	090-1166	561645	PRESSURE RELIEF SWITCH
L10-2073	<u>501178</u>	3510000147	<u>512328</u>	PUMP&MOTOR ASSY (no motor only)
L10-2073	<u>501178</u>	140-1191	<u>488420</u>	FRONT AIR/ SENSOR
L10-2073	<u>501178</u>	140-1192	<u>474690</u>	REAR HYDRAULIC SENSOR
L10-2073	<u>501178</u>	140-1193	<u>512325</u>	INPUT/OUTPUT I/O AIR MODULE
L10-2073		140-1193	<u>512325</u>	MODULE, AIR I/O SENSOR LEVEL 140-1193 (VTL01A006-1)
L10-2073	<u>501178</u>	140-1194	<u>464734</u>	TOUCH PAD (VTL02A005- 1)
L10-2073	<u>501178</u>	141-0017	*3*	WIRE HARNESS (RUNS LENGTH OF COACH)
L10-2073	<u>501178</u>	141-0016014		wire harness for pump motor assy (short har)
L10-2073	<u>501178</u>	VTL03A008-1		IS POWER GEAR VPN # 501186
L10-2073	<u>501178</u>			PUMP/MOTOR ASSY
L10-2073	<u>501178</u>			LEVELER HYD / AIR SYS 4PT
L10-2073	<u>501178</u>	500439	<u>309222</u>	LEG VALVE ASSY (EXTEND AND RETRACT)
L10-2070	500306	500145	088507	REAR JACK
L10-2070	500306	500146	073677	FRONT JACK
L10-2070	500306	500299	137200	FLOAT SWITCH / LEVEL SENSOR
L10-2070	500306	<u>500453</u>	<u>251052</u>	PUMP/MOTOR ASSY
L10-2062	500275	500146	073677	REAR & FRONT JACK

L10-2062	500275	800129S	<u>407220</u>	SEAL KIT FOR 500146 JACKS FRONT/REAR
L10-2062	500275	500278	303632	POWER UNIT
L10-2062	500275	<u>13-1064</u>	*2*	PUMP/MOTOR ASSY
L10-2062	500275	800038S		TANK REPLACEMENT KIT
L10-2062	500275	500099	<u>084178</u>	SOLENOID/MANIFOLD VALVE
L10--2061	500257			LEVELER, HYDRAULIC SYSTEM, SPARTAN /MILWAUKEE
L10--2061	500257	500145	088507	JACK
L10-2058	500284	500299	137200	FLOAT SWITCH
L10-2058	500284	<u>500453</u>	<u>251052</u>	POWER UNIT
L10-2056	500365	500439	<u>309222</u>	LEG VALVE ASSY (EXTEND AND RETRACT)
L10-2056	500365	500450	<u>350114</u>	float sensor
L10-2054	500578	13-1104		PUMP MOTOR W/SOLENOID
L10-2053	500579	500440	<u>309223</u>	DUMP VALVE SOLENOID
L10-2053	500579	500643	<u>462133</u>	control modue
L10-2053	500579	500070TH	088507	FRONT & REAR JACKS
L10-2053	500579	500439	<u>309222</u>	LEG VALVE ASSY (EXTEND AND RETRACT)
L10-2053	500579	500440	<u>309223</u>	DUMP VALVE ASSY (RETRACTING)
L10-2053	500579	800037S		RESERVIOR/ HYDRAULIC TANK
L10-2053	500579	800131S	376084	SEAL KITS FOR 500070TH
L10-2053	500579		<u>350114</u>	FLOAT SWITCH ASSY
L10-2053	500579	13-1104		PUMP/MOTOR ASSY
L10-2053	500579	500454		MANIFOLD ASSY
L10-2053	500579	13-1045		dipstick
L10-2052	500578	500439	<u>309222</u>	SOLENOID VALVE
L10-2052	500578	500070th	088507	front jack
L10-2052	500578	500620		rear jack
l10-1501	501195	140-1195	<u>483348</u>	touchpad only
F97-0406		<u>1510000011</u>	<u>491553</u>	CONTROLLER - GALLEY/ BEDROOM
F97-0405		1510000013	<u>491554</u>	CONTROLLER - FLUSH FLOOR
f76-8100	<u>9010000392</u>	540091		center roller countersunk
f76-8100	<u>9010000392</u>	540090	554922	roller flush
F76-8052	<u>540171-</u> traditional hyd gen slide kit	540172	<u>521812</u>	CYLINDER/ RAM ASSY

F76-8052	<u>540171 - traditional hyd gen slide kit</u>	<u>090-1171</u>	<u>527771</u>	MANIFOLD W/ SOLENOID ASSY
F76-8052	<u>540171</u>	540074	*1*	GENERATOR SWITCH ONLY
F76-8052	<u>540165- mini hyd gen slide kit</u>	130-1260	<u>527393</u>	CYLINDER ASSY 1X23/ HYD RAM FOR MINI HYD GEN SLIDE
F76-8052	<u>540165-mini hyd gen slide kit</u>	501189	510801	MANIFOLD W/ SOLENOID ASSY
F76-8052	<u>540165- mini hyd gen slide kit</u>	<u>130-1261</u>	<u>476274</u>	MIN-HYDRAULIC PUMP ASSY (Complete) Includes pump/motor assy and Manifold/Valve assy
F76-8051	<u>540155</u>	540074		SWITCH ASSY G.S. DPDT
F76-8051	<u>540155</u>	540090	554922	ROLLER
F76-8051	<u>540155</u>	540091		SIDE ROLLER
F76-8051	<u>540155</u>	540098		RIGHT SIDE GEN SLIDE RAIL ASSY
F76-8051	<u>540155</u>	540099		LEFT SIDE GEN SLIDE RAIL ASSY
F76-8051	<u>540155</u>	540109	307296	PUMP ASSY PRIOR TO '06
F76-8051	<u>540155</u>	540162		RAM CYLINDER ASSY WITH LOCKING VALVE
F76-8051	<u>540171</u>	540167	<u>507546</u>	PUMP ONLY FOR 540171 TRADITIONAL GEN SLIDE (PART OF 540168 PUMP/MANIF)
F76-8051	<u>540171</u>	540168	483344	PUMP ASSY W/ MANIFOLD FOR 540171 TRADITIONAL GEN SLIDE
F76-8051	<u>540109</u>	06-1018		BREATHER VENT CAP FOR RESERVIOR (THIS PART WILL BE OBSOLETE WHEN POWER GEAR IS OUT OF STOCK.
F76-8051	<u>540155</u>	06-1018		BREATHER VENT CAP FOR RESERVIOR PART OF 540109 (THIS PART WILL BE OBSOLETE WHEN VENDOR STOCK IS GONE)
F76-8051		06-1018		BREATHER CAP

F76-8051	<u>130-1261</u>	130-1266	537638	PUMP ONLY FOR MINI HYD SYS 540155 (THIS IS PUMP/MOTOR ONLY with tank. (No manifold/valve) PART OF 130-1261)
F76-8051	<u>540155</u>	130-1267S	<u>510803</u>	HYD PUMP ASSY FOR '06 AMER. COACH
F76-8051	<u>540155</u>	15-1370		SPIN LOCK NUT 1/2 - 13
F76-8051	<u>540155</u>	15-1423		Bolt Carriage 3/8 - 16 1/2 65
F76-8051	<u>540155</u>	15-1424		NUT FLL SERRATED 3/8 - 16 65
F76-8051	<u>540155</u>	15-1427		HHCS 1/2-13 X 1-3/4
F76-8051	<u>540155</u>	15-1430		HHCS 1/2-13 X 1-1/4
F76-8051	<u>540155</u>	16-1024		FLAT WASHER 1/2
F76-8051	<u>540155</u>	18-1029		COTTER PIN
F76-8051	<u>540155</u>	18-1055		CLEVIS PIN
F76-8051	<u>540155</u>	19-1013		BRONZE BUSHING 3/4 X 1/2 X 7/8
F76-8051	<u>540155</u>	19-1014		BRONZE BUSHING 3/4 X 1/2 X 21/32
F76-8051	<u>540155</u>	AAS-HOSE-900		HOSE ASSY
F76-8051	<u>540165- mini hyd gen slide kit</u>	AAS-HOSE-900		HOSE-FOR MINI-HYD GEN SLIDE
F76-8051	<u>540155</u>	DPF8030-094		COUPLER KIT
F76-8050	<u>540000</u>	540002		CYLINDER (RAM) ASSY
F76-8050	<u>540000</u>	540109	307296	PUMP MOTOR ASSY
F76-8050	<u>540000</u>			HYD GEN SLIDE KIT
F76-3554	<u>540143</u>	540109	307296	PUMP ASSY
F76-3554	<u>540143</u>	540144	449139	RAM/CYLINDER
F76-3553	540082	540077		cylinder assy
f76-3553	540082	540075		cylinder only
F76-3552	<u>540080</u>			GEN SLIDE OUT ASSY KIT
F76-3551	540081	540006		LOCK VALVE
F76-3551	540081	540074	<u>300613</u>	SWITCH ONLY
F76-3550	<u>540020</u>	<u>090-1171</u>	<u>527771</u>	MANIFOLD W/ SOLENOID ASSY
F76-3550	<u>540020</u>	540074	<u>300613</u>	SWITCH ONLY
b50-9808	<u>9010000560</u>	1010001025		motor only
B50-8260	520620	520044	*4*	SHAFT DRIVE ASSY
B50-8260	520620	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-8155	670181	320-0018		NYLON SLIP PLATE WHITE
B50-8108	670179	320-0018		NYLON SLIP PLATE WHITE
B50-8060	800025			SLIP PLATE/ TEFLON

B50-8055	800088			RAMP KIT
B50-6200	<u>1010000015</u>			S/O ASSY BRACKET KIT
B50-6102	800275		441782	END BRACKET KIT FOR SLIDE OUT
B50-6100		522176	464508	MOTOR
B50-6002		521292	<u>336367</u>	MOTOR
B50-6002		521638	<u>263287</u>	RELAY KIT
B50-6002				IF THIS IS AN '03 MALLARD - THIS S/O SYSTEM CAME AS PART OF THE LIPPERT CHASSIS. MOST LIKELY SYSTEM IS PG SYS#520620 BUT IT WOULD NEED TO BE VERIFIED WITH LIPPERT.
B50-6002		521748	<u>336367</u>	MOTOR
B50-6002		523387	<u>336367</u>	MOTOR
B50-6002		522243S	<u>263287</u>	RELAY KIT
b50-4095	905898028	1812995		LIMIT SWITCH
B50-4094	905857201	3621130	*1*	ROD RELEASE LEVER FOR TRAY SLIDE
B50-2040	<u>521277</u>	530026		SPUR GEAR
B50-0901	520620	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0901	520620	523387	<u>336367</u>	MOTOR
B50-0901	520620	18-1039	<u>238957</u>	ROLL PIN 1/4" x 1 1/2"
B50-0803		520317	<u>331609</u>	MOTOR
B50-0713	520175	522895	<u>385165</u>	MOTOR
B50-0713	<u>520969</u>	520685		BASE ASSY - MOTOR MOUNT ONLY
B50-0713	<u>520969</u>	520971	*3*	INNER RAIL ASSY
B50-0713	<u>520969</u>	520975		BASE ASSY W/ GEARS, NUTS, ETC
B50-0713	<u>520969</u>	522802	<u>385165</u>	MOTOR
B50-0705	520181	520084	<u>331609</u>	MOTOR
B50-0705	520181	522895	<u>385165</u>	MOTOR
B50-0701	520175	522895	<u>385165</u>	MOTOR
B50-0701	520175	140-1130	<u>246063</u>	RELAY CONTROL
B50-0655	<u>522084</u>	522262	*1*	FRAME FOR S/O ASSY
B50-0655	<u>522084</u>	522895	<u>385165</u>	MOTOR
B50-0655	<u>522084</u>	18-1039		PIN
B50-0655	<u>522084</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0628				32 SERIES STEP
B50-0605	522705	520819	464733	MOTOR
B50-0605	522705	522977	497772	INNER RAIL (RIGHT) W/ STOP

B50-0601	521795	523387	<u>336367</u>	motor
b50-0459	524164	522895s	<u>385165</u>	motor
B50-0495	523745	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0495	523745	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0495	523745	523498	<u>449263</u>	MOTOR
B50-0490	<u>523334</u>	520744		GEAR SHAFT ASSY KIT
B50-0490	<u>523334</u>	522802	410666	MOTOR
B50-0490	<u>523334</u>	532110		DRIVE SHAFT
B50-0490	<u>523334</u>	532128		DRIVE SHAFT ASSY (W/GEAR)
B50-0490	<u>523334</u>	140-1130	<u>246063</u>	CONTROLLER
B50-0490	<u>523334</u>	DN13747	<u>390833</u>	SPUR GEAR
B50-0462	<u>524765</u>	524411	<u>521635</u>	MOTOR
B50-0462	<u>524765</u>			S/O ASSY ELEC BEDROOM R/S
B50-0462	<u>524765</u>	140-1213	465478	CONTROL MODULE
B50-0462	<u>524765</u>	250-0011		spur gear (28 teeth)
B50-0460	<u>532295</u>	522895	<u>385165</u>	MOTOR
B50-0460	<u>532295</u>			S/O ASSY ELEC BEDROOM DOORSIDE
B50-0460	<u>532295</u>	501176	*1*	FLUSH FLOOR BOX END CONDITION
B50-0460	<u>532295</u>	531178	*2*	PLATE END CONDITION
B50-0457	<u>531143</u>	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0457	<u>531143</u>	522895	<u>385165</u>	MOTOR
B50-0457	<u>531143</u>	531156		INNER RAIL (RIGHT SIDE)
B50-0457	<u>531143</u>	140-1213	465478	CONTROL MODULE
B50-0457	<u>531143</u>			LIMIT SWITCH
B50-0455	<u>523205</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
b50-0455	<u>523205</u>	524276	483349	MOTOR
B50-0455	<u>523205</u>	140-1130	<u>246063</u>	CONTROL RELAY
B50-0455	<u>523205</u>	14-1138	<u>445463</u>	(6 pin) WIRE HARNESS
B50-0455	<u>523205</u>	18-1039	<u>238957</u>	COIL PIN/ SHEAR PIN
B50-0451	<u>521931</u>	521286	<u>385165</u>	MOTOR
B50-0451	<u>521931</u>	510104		SPUR GEAR (24 teeth)
B50-0451	<u>521931</u>	140-1130	<u>246063</u>	CONTROL BOARD
B50-0413	<u>524826</u>	250-0010	<u>507555</u>	SPUR GEAR
B50-0413	<u>524826</u>	<u>1010000803</u>	<u>537058</u>	MOTOR - SAME FOR ALL 4 RAILS
B50-0413	<u>524826</u>			FULL WALL SLIDE
B50-0413	<u>524826</u>	140-1249	<u>507547</u>	CONTROLLER
B50-0412	<u>524533</u>			S/O ASSY FL/FL ELEC FULL WALL
B50-0412	<u>524533</u>	140-1249	<u>507547</u>	CONTROLLER
B50-0412	<u>524533</u>	510036	<u>456944</u>	BUSHINGS (2 PER RAIL)

B50-0412	<u>524533</u>	521336	<u>472727</u>	WOODRUFF KEY
B50-0412	<u>524533</u>	524027		OUTER RAIL ASSY (FRONT & REAR)
B50-0412	<u>524533</u>	524029		OUTER RAIL ASSY (MIDDLE ONLY)
B50-0412	<u>524533</u>	524035	520855	SHAFT ASSY W/COUPLER
B50-0412	<u>524533</u>	524534	513130	INNER RAIL ASSY (REAR)
B50-0412	<u>524533</u>	524550	*2*	INNER RAIL ASSY (FRONT & MIDDLE)
B50-0412	<u>524533</u>	800325	475257	BRACKET KIT
B50-0412	<u>524533</u>	800329		ANTI JUMP KIT FOR FW SLIDE
B50-0412	<u>524533</u>	140-1189	<u>534006</u>	MOTOR SENSOR (ENCODER)
B50-0412	<u>524533</u>	15-1412	537078	SET SCREW
B50-0412	<u>524533</u>	250-0010	<u>507555</u>	SPUR GEAR
B50-0412	<u>524533</u>			
B50-0412	<u>524533</u>			FULL WALL SLIDE OUT
B50-0412	<u>524533</u>	524907	<u>537058</u>	MOTOR
B50-0411	<u>524533</u>	140-1249	<u>507547</u>	CONTROLLER
B50-0411	<u>524533</u>	524120	<u>537058</u>	MOTOR W/ SENSOR
B50-0411	<u>524533</u>	524534	513130	(REAR) INNER RAIL ASSY
B50-0411	<u>524533</u>	524550		(FRONT & MIDDLE) INNER RAIL ASSY
B50-0410	<u>524026</u>	521910		GSO BRACKET
B50-0410	<u>524026</u>	524028	*1*	REAR OUTER RAIL
B50-0410	<u>524026</u>	520638		GEAR RACK ASSEMBLY 34C
B50-0410	<u>524026</u>	524120	<u>537058</u>	MOTOR
B50-0410	<u>524026</u>	524297	<u>512326</u>	REAR INNER RAIL
B50-0410	<u>524026</u>	140-1175	<u>456939</u>	CONTROLLER
b50-0410	<u>524026</u>	250-0010	<u>507555</u>	SPUR GEAR
b50-0408	901000056	151000013	<u>491554</u>	control modULE
B50-0406	<u>523035</u>	510022	<u>520621</u>	ROLLER (SUPPORT EDGE OF OUTER RAIL)
B50-0406	<u>523035</u>	520014	<u>112839</u>	ROLLER (BY SPUR GEAR)
B50-0406	<u>523035</u>	521897		INNER RAIL ASSY
B50-0406	<u>523035</u>	522480	<u>459063</u>	SPUR GEAR
B50-0406	<u>523035</u>	523900	<u>443174</u>	MOTOR
B50-0406	<u>523035</u>	524297	<u>512326</u>	INNER RAIL ASSY
B50-0406	<u>523035</u>	<u>140-1163</u>	<u>407217</u>	CONTROL BOARD/TOUCH PAD
B50-0406	<u>523035</u>	150-1490		BOLT TO SECURE X-TUBE TO SLIDE RAIL 1/4 / 20 X 1.5

B50-0406	<u>523035</u>	15-1441		LOCK NUT GOES W/ 150-1490
B50-0406	<u>523035</u>	16-1037		WASHER .25. GOES W/ 150-1490
B50-0405	<u>521873</u>	510022	<u>520621</u>	ROLLER (EXTERNAL)
B50-0405	<u>521873</u>	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0405	<u>521873</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0405	<u>521873</u>	520370		ROLLER (INSIDE RAIL)
B50-0405	<u>521873</u>	521066	<u>348582</u>	MOTOR
B50-0405	<u>521873</u>	524327		maxi torque motor (hi torque)
B50-0405	<u>521873</u>	521080		GEAR SHAFT
B50-0405	<u>521873</u>	521906		MOUNTING PLATE BRACKET
B50-0405	<u>521873</u>	140-1130	<u>246063</u>	CONTROL BOARD/ CONTROLLER
B50-0405	<u>521873</u>	15-1006		NUT
B50-0405	<u>521873</u>	15-1343		SCREW 1/4-20 X 1 1/2
B50-0405	<u>521873</u>	16-1037		WASHER LOCK 1/2
B50-0405	<u>521873</u>	18-1032	<u>472728</u>	PIN CLIPS
B50-0405	<u>521873</u>	18-1039	<u>238957</u>	COIL PIN
B50-0405	<u>521873</u>	522068S		SHAFT KIT -- CONTAINS 1 SHAFT 521080, 1 SPUR GEAR 510104, 2 BEARING SLEEVES 510036, 4 WASHERS 16-1037, 1 NUT 15-1006, 1 SCREW 15-1343, 2 PIN CLIPS 18-1032, 1 COIL PIN 18-1039
B50-0404	<u>901000013</u>			S/O ASSY FLUSH FLOOR - WAS 532285
B50-0404	<u>901000013</u>	531174	*1*	FLUSH FLOOR BOX END CONDITION
B50-0404	<u>901000013</u>	531178	*2*	PLATE END CONDITION
B50-0404	<u>901000013</u>	15-1348	<u>568558</u>	LOCK NUT
B50-0404	<u>532285</u>	1010001556	<u>402133</u>	MOTOR
B50-0404	<u>901000013</u>	1010001556	<u>402133</u>	MOTOR
B50-0404	<u>532285</u>	531199		SQUARE TUBE DRIVE SHAFT ASSY
B50-0404	<u>532285</u>			FLUSH FLOOR SLIDE OUT
B50-0403	<u>531114</u>	510116	<u>113887</u>	CURRENT LIMITER SWITCH/ CONTROLLER
B50-0403	<u>531114</u>	522479	<u>515594</u>	ROLLERS
B50-0403	<u>531114</u>	522479	<u>515594</u>	ROLLER
B50-0403	<u>531114</u>	522480	<u>459063</u>	SPUR GEAR
B50-0403	<u>531114</u>	522480	<u>459063</u>	SPUR GEAR

B50-0403	<u>531114</u>	1010001556	<u>402133</u>	MOTOR
B50-0403	<u>531114</u>	531082	<u>490562</u>	SHAFT - 9.43" X 3/4"
B50-0403	<u>531114</u>	531082	<u>490562</u>	SHAFT
B50-0403	<u>531114</u>	531119		OUTER RAIL ASSY
B50-0403	<u>531114</u>	531120		INNER RAIL ASSY
B50-0403	<u>531114</u>	531167		DRIVE SHAFT COUPLER ASSY
B50-0403	<u>531114</u>	531179	568557	ANGLE LOWER END CONDITION BRACKET
B50-0403	<u>531114</u>	800170		ROOM MOUNTING KIT (SAME FOR BOTH SIDES)
B50-0401		522462	<u>355060</u>	MOTOR
B50-0400	<u>531097</u>	531087	<u>355059</u>	MOTOR
B50-0400	<u>531097</u>	13-1113	<u>355059</u>	MOTOR
B50-0400	<u>531097</u>	15-1348	568558	LOCK NUT
B50-0400	<u>531097</u>	531093	*1*	OUTER RAIL ASSY
b50-0394	<u>9010000568</u>	<u>140-1163</u>	<u>407217</u>	control module
B50-0391	<u>9010000267</u>	1010001663	585397	MOTOR ONLY
B50-0390	<u>9010000151</u>			S/O ASSY CENTER DRIVE ELEC MAIN ABOVE FLOOR
B50-0390	<u>9010000151</u>	1010001663	585397	motor only
b50-0386	<u>9010000312</u>			MANUAL CONTROL KIT
B50-0385	<u>9010000311</u>	1010000682		MOTOR ONLY
B50-0380	<u>9010000190</u>			S/O ASSY ELEC MAIN ABOVE FLOOR
B50-0380	<u>9010000190</u>	1010000682		MOTOR ONLY
B50-0375	<u>523580</u>	522802	<u>385165</u>	MOTOR
B50-0375	<u>523580</u>	DN12854		NUT FOR STOP (NEED QTY 2)
B50-0375	<u>523580</u>	DN13690		STOP
B50-0375	<u>523580</u>	DN13766		BOLT FOR STOP (NEED QTY 2)
B50-0375	<u>523580</u>	140-1130	<u>246063</u>	CONTROLLER
B50-0375	<u>523580</u>	523884		WEAR BUTTON
b50-0371	<u>9010000497</u>	1010001025		motor only
B50-0364	<u>9010000258</u>	1010001025		new motor w/hall effect sensor
B50-0364	<u>9010000258</u>	<u>1010000803</u>		old motor w/encoder
b50-0364	<u>9010000258</u>	<u>1510000165</u>		control unit only
B50-0363	<u>9010000014</u>	18-1036	<u>467339</u>	ROLL PIN (ALL 4 RAILS)
B50-0363	<u>9010000014</u>	18-1007	<u>464963</u>	SHEER PIN (COIL PIN) (ALL 4 RAILS)
B50-0363	<u>9010000014</u>	<u>1010000083</u>		RAIL ASM MAINROOM MOTOR LP
B50-0363	<u>9010000014</u>	<u>1010000086</u>		RAIL ASM MAINROOM DRIVE LP

B50-0363	<u>9010000014</u>	<u>1010000203</u>		RAIL ASM MAINROOM DRIVE LP
B50-0363	<u>9010000014</u>	<u>1010000803</u>	<u>537058</u>	MOTOR - SAME FOR ALL 4 RAILS
B50-0363	<u>9010000014</u>	522480	<u>459063</u>	SPUR GEAR (ALL 4 RAILS)
B50-0363	<u>9010000014</u>		510265	FULL WALL (4 RAIL) SLIDE
B50-0362	<u>9010000015</u>	<u>1010000203</u>		RAIL ASSY - MAIN ROOM (4TH RAIL)
B50-0362	<u>9010000015</u>	<u>1010000083</u>		RAIL ASSEMBLY MAINROOM (1ST AND 2ND RAIL)
B50-0362	<u>9010000015</u>	<u>1010000086</u>		RAIL ASSY - MAIN ROOM (3RD RAIL)
B50-0362	<u>9010000015</u>	140-1249	<u>507547</u>	CONTROL MODULE
B50-0362	<u>9010000015</u>	522480	<u>459063</u>	SPUR GEAR
B50-0362	<u>9010000015</u>	<u>1010000803</u>	<u>537058</u>	4 RAIL - FULL WALL SLIDE OUT
B50-0362	<u>9010000015</u>	531205		SHAFT W/ COUPLER
B50-0362	<u>9010000015</u>	1010001025		motor only
B50-0358	<u>9010000293</u>	<u>1010000803</u>	<u>537058</u>	MOTOR ONLY (ALL 4 SAME)
B50-0358	<u>9010000293</u>	140-1249	<u>507547</u>	CONTROLLER
B50-0351	<u>523688</u>	523823	463208	MOTOR
B50-0351	<u>523688</u>	320-0009		INNER ROLLER (BY MOTOR)
B50-0351	<u>523688</u>	320-0015	*3*	OUTER ROLLER (SUPPORT EDGE OF OUTER RAIL)
B50-0351	<u>523688</u>			ROLLERS
B50-0351	<u>523688</u>			ROLLERS
B50-0350	<u>523640</u>	523823	463208	MOTOR
B50-0324	<u>9010000262</u>			S/O ASSY CENTER DRIVE ELEC MAIN
B50-0324	<u>9010000262</u>	190-1027		BUSHING
B50-0324	<u>9010000262</u>	523823	463208	MOTOR
B50-0324	<u>9010000262</u>	320-0015	*3*	ROLLER - SUPPORTS OUTER RAIL
B50-0324	<u>9010000262</u>	190-1027		BUSHING
B50-0323	<u>2510000003</u>			S/O ASSY CTR DRIVE ELEC MAIN
B50-0323	<u>2510000003</u>	522480	<u>459063</u>	SPUR GEAR
B50-0323	<u>2510000003</u>	1010000010	<u>500790</u>	MOTOR
B50-0323	<u>2510000003</u>	DN13028		WOODRUFF KEY
B50-0323	<u>2510000003</u>	<u>140-1163</u>	<u>407217</u>	CONTROLLER
B50-0322	<u>2510000002</u>	523823	463208	MOTOR
B50-0322	<u>2510000002</u>			ASSY-S/O CTRDR ELEC MN(L MDL)

B50-0320	<u>523300</u>	523823	463208	MOTOR
B50-0320	<u>523300</u>	540066		COUPLING
B50-0320	<u>523300</u>	18-1007	<u>464963</u>	PIN
B50-0320	<u>523300</u>	15-1357		BOLTS 3/8-16X4 1/2
B50-0320	<u>523300</u>	16-1050		WASHER - FLAT 3/8
B50-0320	<u>523300</u>	15-1341		NUT, CENTER LOCK 3/8-16
B50-0320	<u>523300</u>			inner rails
B50-0300	<u>521675</u>	523725	<u>348582</u>	MOTOR
B50-0298	<u>9010000046</u>			S/O ASSY LO-PRO BEDROOM
B50-0298	<u>9010000046</u>	1010000188	548559	MOTOR, ASSY MID TRQ W/PIN
B50-0298	<u>9010000046</u>	<u>1510000011</u>	<u>491553</u>	CONTROLLER/ CONTROL MODULE
B50-0297	<u>523152</u>	523498	<u>449263</u>	MOTOR
B50-0297	<u>523152</u>	<u>140-1163</u>	<u>407217</u>	CONTROLLER
B50-0296		522895	<u>385165</u>	MOTOR
b50-0296	<u>521082</u>	521278		controller
B50-0295		521271	<u>350113</u>	MOTOR
B50-0294	<u>522825</u>	522895	<u>385165</u>	MOTOR
B50-0294	<u>522825</u>	<u>140-1163</u>	<u>407217</u>	CONTROLLER
B50-0292	524294D	523900	<u>443174</u>	MOTOR
B50-0292	<u>523034</u>	510022	<u>520621</u>	OUTER ROLLER (SUPPORT EDGE OF OUTER RAIL)
B50-0292	524294D	510022	<u>520621</u>	OUTER ROLLER (SUPPORT EDGE OF OUTER RAIL)
B50-0292	<u>523034</u>	520014	<u>112839</u>	INNER ROLLER (BY MOTOR)
B50-0292	524294D	520014	<u>112839</u>	INNER ROLLER (BY MOTOR)
B50-0292	<u>523034</u>	523900	<u>443174</u>	MOTOR
B50-0292	<u>523034</u>	<u>140-1163</u>	<u>407217</u>	CONTROL BOARD/TOUCH PAD
B50-0292	<u>523034</u>	523445		inner rail
B50-0292	<u>523034</u>	522480	<u>459063</u>	spur gear
B50-0292	524294d	524296		inner rail
b50-0292	<u>523034</u>	521771	512327	drive shaft assy
B50-0292	<u>524294</u>	522480	<u>459063</u>	spur gear
B50-0290	<u>523092</u>	523823	463208	MOTOR
B50-0290	<u>523092</u>	521066	<u>348582</u>	MOTOR
B50-0290	<u>523092</u>	320-0009	472729	OUTER ROLLER (GOES BY MOTOR)
B50-0290	<u>523092</u>	320-0015	*3*	ROLLER SUPPORTS OUTER RAIL
B50-0289	<u>523093</u>			MOTOR
B50-0287	<u>521481</u>	140-1130	<u>246063</u>	CONTROL BOARD

B50-0287	<u>521481</u>	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0287	<u>521481</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0287	<u>521481</u>	521066	<u>348582</u>	MOTOR
B50-0287	<u>521481</u>	521080		GEAR SHAFT
B50-0287	<u>521481</u>	15-1006		NUT
B50-0287	<u>521481</u>	15-1343		SCREW 1/4-20 X 1 1/2
B50-0287	<u>521481</u>	16-1037		WASHER LOCK 1/2
B50-0287	<u>521481</u>	18-1032	<u>472728</u>	PIN CLIPS
B50-0287	<u>521481</u>	18-1039	<u>238957</u>	COIL PIN
B50-0287	<u>521481</u>	522068S		SHAFT KIT -- CONTAINS 1 SHAFT, 1 SPUR GEAR, 2 BEARING SLEEVES, 4 WASHERS, 1 NUT, 1 SCREW, 2 PIN CLIPS, 1 COIL PIN
B50-0286	521050	520488	<u>331609</u>	MOTOR
B50-0286	521050	140-1130	<u>246063</u>	CONTROL BOARD
B50-0286	521050	510022	<u>520621</u>	inner rollers
B50-0286	521050	520653		
B50-0285	521052	510022	<u>520621</u>	ROLLERS
B50-0285	521052	520488	<u>331609</u>	MOTOR
B50-0285	521052	140-1130	<u>246063</u>	CONTROL BOARD
B50-0285	521052	15-1341		NUTS FOR 510022
B50-0285	521052	15-1378		SHOULDER BOLTS FOR 510022
B50-0284	521480	523725	<u>348582</u>	MOTOR ONLY
B50-0278	<u>2510000001</u>			S/O ASSY ELEC MAIN ABOVE FLOOR
B50-0278	<u>2510000001</u>	510022	<u>520621</u>	ROLLERS- AT END OF OUTER RAIL, CAN SEE IN PRINT.
B50-0278	<u>2510000001D</u>	510022	<u>520621</u>	ROLLERS- AT END OF OUTER RAIL, CAN SEE IN PRINT.
B50-0278	<u>2510000001</u>	520014		ROLLER, IN MIDDLE OF OUTER RAIL. CANNOT SEE IN BASIC S/O PRINT
B50-0278	<u>2510000001D</u>	520014		ROLLER, IN MIDDLE OF OUTER RAIL. CANNOT SEE IN BASIC S/O PRINT
B50-0278	<u>2510000001</u>	523446		REAR INNER ASSY
B50-0278	<u>2510000001D</u>	524297	<u>512326</u>	REAR INNER ASSY
B50-0278	<u>2510000001D</u>	1010000010	<u>500790</u>	MOTOR ONLY (can not get spur gear separate)
B50-0278	<u>2510000001</u>	<u>140-1163</u>	<u>407217</u>	CONTROLLER
B50-0278	<u>2510000001D</u>	<u>140-1163</u>	<u>407217</u>	CONTROLLER

B50-0278	<u>2510000001</u>	522480	<u>459063</u>	SPUR GEAR
B50-0274		521286	<u>385165</u>	MOTOR
B50-0274		520717	136711	GEAR SHAFT ASSY KIT FOR SGL RL 3X3
b50-0273	520928	510104	<u>332889</u>	SPUR GEAR (24 teeth)
b50-0273	520928	520039	*3*	SHAFT FOR SPUR GEAR
b50-0273	520928	522895	<u>385165</u>	MOTOR
b50-0273	520928	18-1039	<u>238957</u>	PIN
B50-0272	520380	520554	<u>385165</u>	MOTOR
B50-0272	520380	18-1039	<u>238957</u>	COIL PIN
B50-0271	523698	523786	*1*	MOTOR
B50-0270	523295	521271	<u>350113</u>	MOTOR
B50-0269	<u>520610</u>	510022	<u>520621</u>	ROLLERS
B50-0269	<u>520610</u>	520488	<u>331609</u>	MOTOR
B50-0269	<u>520610</u>	14-1098	<u>122860</u>	RELAY CONTROL
B50-0269	<u>520610</u>	18-1039	<u>238957</u>	COIL PIN
B50-0268	<u>520605</u>	520014	<u>112839</u>	ROLLERS
B50-0268	<u>520605</u>	520317S	<u>112839</u>	MOTOR
B50-0257	<u>600312</u>	130-1284		PUMP/RESERVIOR ASSY
B50-0257	<u>600312</u>	140-1197	497523	SWITCH BEZEL ASSY
B50-0257	<u>600312</u>	600298		lh cable
B50-0257	<u>600312</u>	080-1079		cable
B50-0257	<u>600312</u>	<u>130-1275</u>		cable assy
B50-0248	<u>521620</u>	510036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0248	<u>521620</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0248	<u>521620</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0248	<u>521620</u>	521292	<u>385165</u>	MOTOR
B50-0248	<u>521620</u>	521621		OUTER RAIL
B50-0248	<u>521620</u>	<u>521642</u>		INNER RAIL ASSY
B50-0248	<u>521620</u>	522895	<u>385165</u>	MOTOR
B50-0248	<u>521620</u>	140-1213	465478	CONTROLLER
B50-0248	<u>521620</u>	520717	136711	GEAR SHAFT ASSY KIT FOR SGL RL 3X3
B50-0247	<u>520387</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0247	<u>520387</u>	521286	<u>385165</u>	MOTOR
B50-0247	<u>520387</u>	522895	<u>385165</u>	MOTOR
B50-0247	<u>520387</u>	14-1130	<u>246063</u>	RELAY CONTROL
b50-0247	<u>520387</u>	18-1039	<u>238957</u>	SHEAR PIN
B50-0246	520300	520343		OUTER RAIL DRIVE ASSY
B50-0246	520300	14-1098	<u>122860</u>	RELAY CONTROL
B50-0246	520300	520344		IDLER OUTER RAIL IDLER ASSY
B50-0246	520300	520345		INNER RAIL ASSY FOR BOTH
B50-0246	520300	520488	<u>331609</u>	MOTOR

B50-0246	520300	520717	136711	GEAR SHAFT ASSY KIT FOR SGL RL 3X3
B50-0241	<u>520575</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0241	<u>520575</u>	520317S	<u>331609</u>	MOTOR
B50-0240	<u>531039</u>	510022	<u>520621</u>	ROLLERS 2 PER RAIL/ 2 RAILS IN SYSTEM
B50-0240	<u>531039</u>	510104	<u>332889</u>	SPUR GEAR (24 teeth)
B50-0240	<u>531039</u>	530026	*1*	SPUR GEAR (12 TOOTH)
B50-0240	<u>531039</u>	520317	<u>331609</u>	MOTOR
B50-0240	<u>531039</u>	531020		SHAFT
B50-0240	<u>531039</u>	18-1039	<u>238957</u>	ROLL PIN
B50-0240		5301-125		SHIM
B50-0240	<u>531039</u>	140-1144	<u>368510</u>	CURRENT LIMITER SWITCH/ CONTROLLER
B50-0238		521286	<u>385165</u>	MOTOR
B50-0237	<u>531129</u>	524137	453591	MOTOR
B50-0237	<u>531129</u>			CONTROLLER
B50-0221	<u>9010000492</u>	1010001025		MOTOR ONLY
B50-0221	<u>9010000492</u>	250-0010	<u>507555</u>	drive gear off motor
b50-0220		500036	<u>456944</u>	BEARING SLEEVE, BUSHING
B50-0219	<u>9010000495</u>	1010000010		MOTOR ONLY
B50-0217	<u>9010000360</u>	1010001025	*1*	MOTOR
B50-0205	<u>532290</u>			S/O ASSY ELEC GALLEY
B50-0205	<u>532290</u>	524137	453591	MOTOR
B50-0191		524411	<u>521635</u>	MOTOR ONLY
B50-0191		1010000668		OUTER RAIL ASSY
B50-0191		1010000670		INNER RAIL ASSY
B50-0191		9010000196	515782	
B50-0190		523091		MOTOR ONLY
B50-0190		532271		INNER RAIL
B50-0190		532276		OUTER RAIL
B50-0190		532283	502091	TABLE SLIDE (PRIOR TO NOV. 2006)
B50-0180	<u>906153000</u>	1101430		MOTOR ONLY (PER KEVIN)
B50-0170	<u>9010000310</u>	1010000683		MOTOR ONLY
B50-0170	<u>1010001084</u>	1010000683		MOTOR ONLY
B50-0165	<u>9010000303</u>	<u>140-1163</u>	<u>407217</u>	CONTROL BOARD
B50-0165	<u>9010000303</u>	1010001663	585397	motor only
B50-1050		540113		CYLINDER ASSY
B50-1050		540109		PUMP/MOTOR ASSY
B49-0009	<u>130-1261</u>	501189	510801	MANIFOLD ASSY. This does not include the Pump/Motor assy
B49-0009	<u>540168</u>	540167	<u>507546</u>	PUMP ONLY P/O SYSTEM 540170

B49-0009	<u>540165</u>	AAS-HOSE-900		7 FT HOSE FOR GEN SLIDE OR STEP COVER (INTAKE & OUTTAKE HOSES) FOR MINI HYDRAULIC SYSTEM 540165 (PUMP 130-1261) INPUT/OUTPUT MEASURES 1/4"
B49-0009	<u>540165</u>	080-1099		16 FT HOSE. LONGER HOSE FOR GEN SLIDE OR STEP COVER (INTAKE & OUTTAKE HOSES) FOR MINI HYD SYSTEM # 540165 (PUMP 130-1261) INPUT/OUTPUT
B49-0009		540168	483344	GEN SLIDE PUMP & MANIFOLD KIT THIS IS A BIGGER PUMP THAN THE MINI HYDRAULIC SLIDE. IT HAS 1/2" INPUT/OUTPUT HOSES/CONNECTORS
B49-0009	<u>130-1261</u>	130-1266	537638	PUMP/MOTOR ONLY FOR MINI HYDRAULIC PUMP 130-1261. P/OF MINI HYD SYSTEM 540165. 1/4" INPUT/OUTPUT HOSES/CONNECTORS. This is pump/motor and tank. Does not include manifold
B49-0009	<u>540170</u>	<u>521279</u>	<u>520858</u>	RELAY CONTROL KIT 521279 FOR STANDARD 540170
B49-0009	<u>540170</u>	540170	482708	CYLINDER-POP UP HYD STEP CVR KIT -- THIS KIT CONTAINS 1 CYLINDER 130-1309, 1 PUMP 3510000076, 2 HOSES 080-AA110WS, AND 1 RELAY CONTROL 521279 (standard)
B49-0009	<u>540165</u>	130-1260		CYLINDER ASSY 1X23
B49-0009	<u>540165</u>	540165	478852	KIT, HYDRAULIC GEN SLIDE -- THIS KIT CONTAINS 1 CYLINDER 130-1260, 1 MINI-HYD PUMP 130-1261, 2 HOSES AAS-HOSE-900, AND 1 RELAY CONTROL 521279

B49-0009	<u>540170</u>	540168	483344	PUMP AND MANIFOLD, ONLY FOR STANDARD 540170
B49-0009	<u>540170</u>	080-AA110WS	483341	HOSES 080-AA110WS, FOR STANDARD 540170 INPUT/OUTPUT 1/2" HOSE/CONNECTORS
B49-0009	<u>540170</u>	130-1309	520856	CYLINDER ASSY 23" STROKE, 1 " BORE
B49-0009	<u>540170</u>	130-1309	520856	CYLINDER 130-1309 FOR STANDARD 540170
B49-0009		108AES32-PRR-1H- 07-07-Y / 645432		this is a parker Oildyne part # that is on our pop-up hyd step cover kit # 3510000076 spn 533460
B49-0008				THIS IS SAME AS B49- 0009 see B49-0009 for info.
B39-0651	902813001	909520000	<u>568578</u>	motor only (for units 1999- 2005)
B39-0651	902813001	1101428	<u>490576</u>	motor only (for units newer than 2005)
B39-0651	902813001	909506003	<u>236643</u>	STEP CONTROL MODULE
B39-0651	902813001	909533000		linkage only
b39-0640	902509000	1820124		motor only
b39-0640	902509000	909510000		controller only
b39-0634	901000220	151000140		STEP CONTROL MODULE
b39-0634	901000220	1101428	<u>490576</u>	motor only
b39-0634	901000220	1101425	<u>537565</u>	gearbox/linkage
b39-0634	901000220	1010000824		frame only
B39-0633	902609001	1101428	<u>490576</u>	MOTOR ONLY
B39-0633	902611000	909511000		PC BOARD ONLY
B39-0633	90261100	1101424	*2*	Linkage/gearbox.
B39-0633		909774000		kit for motor, control , and gearbox for either for 903209 or 903211
B39-0633	902611000	908026000		frame only
B39-0632	903211000	90951000	<u>478178</u>	CONTROL MODULE
B39-0632	903211000	1101425	<u>537565</u>	gearbox/linkage
B39-0632	903211000	90951001	*3*	CONTROL BOARD ONLY
B39-0632	903211000	909510000	<u>478178</u>	CONTROL MODULE/ BOX
B39-0632	903211000	214-1001	<u>490576</u>	MOTOR FOR STEP- PWR DBL LAST OUT
B39-0632	903211000		<u>490576</u>	MOTOR FOR STEP- PWR DBL LAST OUT
B39-0632	903211000		450706	STEP- PWR DBL LAST OUT
B39-0632	903211000		450706	STEP- PWR DBL LAST OUT

B39-0632	903211000	1101425	<u>537565</u>	gearbox/linkage
B39-0632	903211000	1101428	<u>490576</u>	MOTOR ONLY
B39-0632	903211000	1101428	<u>490576</u>	MOTOR ONLY
B39-0632	903211000	909770000	061471	CONVERSION KIT
b39-0632	903211000	903209001		black control board
B39-0632	903211000	909534000		STEP GEAR LINKAGE
B39-0632	903211000	909534000		STEP GEAR LINKAGE
B39-0632	903211000	1102200		CAM STOPS (BOLTS)
B39-0632	903211000	1915260		non skid tape
B39-0632	903211000	130-1309	520856	CYLINDER ASSY 23" STROKE, 1 " BORE
B39-0631	903206000			STEP- POWER DOUBLE LAST OUT
B39-0631	903206000	909770000		upgrade kit (for motor)
b39-0631	903206000	909506003	<u>236643</u>	control box
b39-0631	903206000	909520000	<u>568578</u>	motor only (for units 1999- 2005)
b39-0631	903206000	1101428	<u>490576</u>	motor only (for units newer than 2005)
b39-0631	903206000	909534000		LINKAGE ASSY
B39-0629	902508000	909506000		CONTROLLER FOR STEP
b39-0628	903206000			can not order steps only..would have to order frame
b39-0628	903206000	908032000		frame only
b39-0628	903206000	909534000		linkage
b39-0628		909520000	<u>568578</u>	MOTOR ONLY
b39-0628		909770000	061471	CONVERSION KIT
b39-0628	903206000	909534000		LINKAGE ASSY
b39-0628	903206000	905323000		door switch for step
B39-0627	902606001	909520000	<u>568578</u>	MOTOR ONLY
B39-0627	902606001	909510003		CONTROL MODULE (NEWER VERSION)
B39-0627	902606001	909506003	<u>236643</u>	CONTROL MODULE(OLDER VERSION)
B39-0621	904209000	1102015		FOR 95 AND OLDER ALSO BUSHING
B39-0621	904209000	3392082		gear assy
B39-0621	904209000	1820124		MOTOR ONLY 2005 & NEWER
B39-0621	904209000	3392186		FOR 95 AND OLDER ALSO NEED MOUNTING PLATE BRACKET
B39-0621	904209000	909777000		FOR 2005 AND OLDER GET KIT, CONVERSION (for motor/gear box, controller)
B39-0621	904209000	3392186		Plate (goes w/above)

B39-0621	904209000	1102015		Bushing (goes w/above)
B39-0621	904209000			DOUBLE STEP OUT
B39-0621	904209000			THIS PART IS OBSOLETE, BUT CAN BE REPLACED BY A 904209000.
B39-0621	904209000			NO ORIGINAL PARTS AVAILABLE, HAVE BEEN UPDATED TO NEWER STYLE FOR REPLACEMENT PARTS SUCH AS TO REPLACE GEAR: MUST GET 909777000, 3392186, AND 1102015
B39-0621	904209000	1220056		mounting bolts/spacers
B39-0621	904209000	1910650		bottom slide track
B39-0621	904209000	1910160		top slide track
B39-0620	902806001	909520000	<u>568578</u>	MOTOR ONLY
B39-0620	902806001	909533000		LINKAGE ASSY
B39-0620	902806001	909772000		update kit (includes controller)
L10-2055	500459	500145	088507	ALL THREE JACKS THE SAME
L10-2055	500459	<u>500453</u>	<u>251052</u>	POWER UNIT
L10-2055	500459	800301	<u>475030</u>	PUMP ASSY ONLY
L10-2055	500459	800302	<u>497544</u>	MOTOR ONLY FOR PUMP ASSY
L10-2055	500459	500659S	<u>462133</u>	CONTROL BOX/TOUCH PAD
L10-2055	500459	800036s		hydraulic fluid reservoir
903209001		909770000	061471	CONVERSION KIT
903206001		909770000	061471	CONVERSION KIT
		141-0045200		HARNESS - TOUCHPAD TO CONTROL BOX
		1010001284	<u>574052</u>	control assy, jack w/low voltage level
		141-0053353		SAFETY INTERCONNECT HARNESS 336"
		16-1030		WASHER LOCK 1/2
		15-1339		BOLT, 1/2-20X1.5" GR8
		<u>990-1115</u>	<u>539203</u>	MAGNET FOR JACK SENSOR
		1010000663	<u>514877</u>	KIT, BRKT END COND RS FULL WALL SERVICE BULLETIN
		<u>070-1276</u>	*1*	CHECK VALVE T-FITTING

		141-0050384	536934	HARNESS (141-0050RR384)
		500384	364626	CANNOT GET SEAL KIT FOR 500384 (NOT INCLUDING H OR HR VERSION). MUST REPLACE WITH PG # 501022 KIT ("HR" JACK WITH FITTINGS)
	<u>500893</u>	800036S		TANK REPLACEMENT KIT
	530052	14-1139		ROCKER SWITCH
		524179	512694	MOTOR, ASSY DS HIGH TORQUE W/PIN W/CONN
	521472	524179	512694	521472 NOW SUBS TO 524179
	500210	<u>500455R2</u>	137199	LEVELING CONTROL kit
		501092		THIS IS THE # FOR THE MOTOR ASSY ONLY THAT IS ON THE JACK. MUST DETERMINE IF RIGHT HAND MOTOR OR LEFT HAND MOTOR IS NEEDED. RH MOTOR 1010001019 (SPN 534003) LH MOTOR 1010001018 (SPN 534002)
		14-1096	<u>122860</u>	RELAY CONTROL
		90913	<u>236643</u>	CONTROL BOX 90913 - USE 909506003
		906915120		CONTROL SYSTEM
		906915120		CONTROL SYSTEM - PHASE 2 UPGRADE
		909331000	113639	TAPE, SAFETY, NON-SKID, YELLO 21X6
	90952000	909506003	<u>236643</u>	MODULE & SWITCH
		1510000015		DIODE HARNESS-ALL KWIKEE STEPS
		06004		STEP DIODE HARNESS-ALL KWIKEE STEPS
		1812995		MICRO-STOP SWITCH ON RAIL
		800064	507554	HOSE KIT 4-JACK 6K/9K
		800065	512695	HOSE KIT 4-JACK 9K/12K
		500281		fuse kit
		521245	<u>263287</u>	ASSY, S/O CONTROL KIT
		1510000021-353		HARNESS, SAFETY INTERCONNECT (TO CONTROL FROM PARKING BRAKE)

	320-0018	DN11945	*3*	RIVETS FOR 320-0018 (L/10 X 2)
		140-1229	<u>521634</u>	Control box, DA optimized
	<u>9010000003</u>	140-1224	<u>548838</u>	CONTROL BOX
		140-1224 OG	<u>548838</u>	CONTROL BOX REV 'OK'
		140-1224 OH	<u>548838</u>	REV. "OH" DOES NOT EXSIST . CURRENT REVISION IS "OK". USE 548838
		909770000	061471	CONVERSION KIT
	<u>500893</u>	07-1238		FILL PLUG (SCREW IN BRASS W/ ORING)
	530052	14-1080	<u>113889</u>	KEY SWITCH
	3510000076	3510000075		PUMP ONLY
		<u>250-0005</u>	<u>550208</u>	spur gear - now is a 3010000400
		1010001232	<u>545633</u>	BOOT KIT, W/ METAL CLAMP RING. FOR ELECTRIC JACKS ONLY.
		2010000255		CLAMP ONLY P/O 1010001232 KIT
	500384	500590	515803	SPRING KIT
	<u>540170</u>	130-1309	520856	CYLINDER ASSY 23" STROKE, 1 " BORE
		500629	<u>407218</u>	NOW 140-1226
		500630	<u>407219</u>	must order 500630S which is the 140-1227 plus adapter harness)
		500674	<u>462484</u>	NOW 140-1230
		500675	585302	NOW 140-1231
		140-1170		NOW 140-1228
		140-1178	<u>507556</u>	140-1178 IS REPLACED WITH SPN 521634. SPN 507556 IS THE 140-229 W/ ADAPTER HARNESS NECESSARY TO MAKE 140-1229 WORK WITH OLD 140-1178 SYSTEM
		14-1136	<u>086594</u>	FLOAT SWITCH/ SENSOR
		14-1137		FLOAT SWITCH/SENSOR
	<u>1010000051</u>	<u>1010000056</u>	<u>520857</u>	BRACKET, WELD ELECTRIC JACK KIT
		DN12504	*3*	SLIP PLATE/ TEFLON
		070-1302	483345	ELBOW - 90 DEG FOR HYD GENS SLIDE/STEP COVER
		070-1302	483345	ELBOW, 90 DEG P/OF STEP COVER

	<u>524533</u>	140-1189	<u>534006</u>	SENSOR, ASSY PG 140-1189
		532113	521633	ROLLER RACK
		14-1138	<u>445463</u>	6 wire harness to the 1510000011
		500090		PUMP WIRE HARNESS - IS NOW REPLACED BY PG # 500335
	500146	500094	074794	SPRING ONLY
	500833	500094	074794	SPRING KIT
	500082H	500094	074794	SPRING ONLY
	<u>500893</u>	500097	<u>112837</u>	DUMP VALVE W/ SOLENOID KIT
	500687	500099	<u>084178</u>	SOLENOID/MANIFOLD VALVE
	500338S	500099	<u>084178</u>	VALVE/COIL ASSY
		500147	090998	POWER UNIT
		500149	<u>462133</u>	CONTROL BOX/TOUCH PAD
	500903	500199	86594	FLOAT SWITCH/SENSOR
		500248	<u>462133</u>	NO LONGER AVAIL - SUBS TO 500643
	500498	500252	100307	SPRING KIT
		500279	<u>462133</u>	CONTROL BOX/TOUCH PAD
	500507	500310	<u>507544</u>	SOLENOID
	500890	500310	<u>507544</u>	MOTOR START SOLENOID
		500384		OLDER VERNONS OF THIS JACK CANNOT USE SEAL KIT
		500450	<u>350114</u>	FLOAT SWITCH ASSY
		<u>500453</u>	<u>251052</u>	POWER UNIT
		500505		MANIFOLD VALVE
		500513		FRONT HOSE CONNECTOR KIT
		500535	<u>462133</u>	NO LONGER AVAIL - SUBS TO 500643
		500587		RESERVIOR
		500590	515803	SPRING KIT
	500832	500591	\\	SPRING KIT
		500643	<u>462133</u>	AUTO LEVELING KIT W/TOUCHPAD
		500645	<u>462133</u>	CONTROL BOX/TOUCH PAD
		500730	407226	JACKS
		500814	407224	JACKS
		500832	407223	JACK

		500888	<u>251052</u>	POWER UNIT USE # 500453
		<u>500932</u>	472731	JACK
		501090	511013	PUMP ASSY
		501096	478158	JACK ASSY
	501095	501175		FOOT PAD ONLY -
	501096	501175		FOOT PAD ONLY
		501184		AIR PUMP
		501189	510801	MANIFOLD ASSY
		501233	*2*	MANIFOLD
		510022	<u>520621</u>	ROLLER
		510060		
		510063		
		520015	<u>331609</u>	MOTOR
	520308	520039	*3*	SHAFT FOR SPUR GEAR
		520198		GSO BRACKET
		520223	467338	HEX COUPLING
		520229	<u>331609</u>	MOTOR
		520257	*2*	ROLLER KIT
		520258	<u>136710</u>	SHAFT KIT
		520259	*1*	SHAFT REPLACEMENT KIT
		520316	<u>382265</u>	SWITCH BEZEL ASSY
		520430	<u>385165</u>	MOTOR
		520491	462435	520491 IS NOW MOTOR # 523912
		520654		BRACKET
		520683		
		520716		INNER ROLLER
		520916	549878	OUTER SQUARE DRIVE TUBE
		520916	549878	OUTER SQUARE DRIVE TUBE
		521046		MOTOR 520488 & ELECTRICAL KIT 521281
	<u>521481</u>	521066	<u>348582</u>	MOTOR
		521080		7.25" shaft
		521103	256366	MOTOR
		521281		ELECTRICAL KIT
		521285		COUPLER FOR CRANK SHAFT
		521286	<u>385165</u>	MOTOR
		521286	<u>385165</u>	MOTOR
		521290	<u>385165</u>	MOTOR
		521291	<u>385165</u>	MOTOR
		521292	256363	MOTOR
		521336	<u>472727</u>	WOODRUFF KEY
		521337		GEAR

		521342		MOTOR
	521433S	521435		SHAFT ONLY
		521443		HARDWARE KIT
		521749	<u>385165</u>	MOTOR
		521769		MOTOR
		521770	549879	INNER SQUARE DRIVE TUBE
		521771	512327	DRIVE SHAFT ASSY
	<u>531114</u>	521783		COUPLER KIT
		521795	\	MOTOR
		521971	474954	WEAR PADS
		522479	<u>515594</u>	ROLLER
		522765	<u>368510</u>	CURRENT LIMITER SWITCH/ CONTROLLER
		522802	410666	MOTOR
	13-1096	522895	<u>385165</u>	MOTOR
		522978		INNER RAIL
		523024		SHAFT KIT -- CONTAINS 1 SHAFT (260-0003), 1 SPUR GEAR (250-0001), 2 BEARING SLEEVES (190- 1027), 2 PIN CLIPS (18- 1032), 2 ROLLERS (320- 0009) 1 WOODRUFF KEY (521336)
		523037	<u>443174</u>	MOTOR
	531194	523091	<u>472564</u>	MOTOR
		523143	<u>409218</u>	MOTOR
		523182		MOUNTING BRACKET
	13-1096	523387	<u>336367</u>	MOTOR
		523432	<u>443174</u>	MOTOR - NOW USE 443174
		523446		REAR INNER ASSY IS OK TO SUB 524297
		523449		MOTOR
		523498	<u>449263</u>	MOTOR
		1010001556	<u>402133</u>	MOTOR
	<u>523581</u>	523582		SLIDE ARM ASSY 37" (GOES INTO ROLLER RACK ASSY
		523582		SLIDE ARM ASSY-MAY HAVE TO ORDER KIT 523580 W/OUT MOTOR
		523725	<u>348582</u>	MOTOR
		523853	<u>385165</u>	MOTOR
	<u>523581</u>	523884		WEAR BUTTON
		523900	443174	MOTOR
		523912	462435	MOTOR

	520666S	523982		HIGHER TORQUE MOTOR FOR 520666S
		523982	*3*	MOTOR (W/OUT PIN IN OUTPUT SHAFT)
		523983	464508	MOTOR
		524120	<u>537058</u>	NOW REPLACED BY 101-0000803 MOTOR
		524235	460831	motor
		524377	527395	MOTOR, ULT TQ MX2,DS W/O PIN W/CONN
		530013	135545	MOTOR
	<u>531097</u>	530042		ROLLERS
		531082	<u>490562</u>	DRIVE SHAFT
		531116		RAIL ASSY FF
		531164		SPACER
		531166		SHAFT
		531171		DRIVE SHAFT
		531176	568559	end condition stud anle weld
		531179	568557	angle lower end condition 3/16
		531205		SHAFT WITH COUPLER
		532108	*1*	WHITE WEAR BUTTON
	<u>523581</u>	532113	521633	ROLLER RACK BASE w/camfollowers
		532115		CAMFOLLOWER
		532128	<u>390833</u>	SHAFT ASSY WITH COUPLING
		540006		LOCK VALVE
		540011	307296	PUMP ASSY
		540076		CYLINDER
		540090	554922	ROLLER - FLUSH
		540091		CENTER ROLLER - COUNTERSUNK
		540109		PUMP/MANIFOLD ASSY - NO LONGER AVAILABLE - MUST REPLACE WITH SPN 533460
	540112	540115		LOCK VALVE FOR GEN SLIDE
	540138	540115		LOCK VALVE FOR GEN SLIDE
	540142	540115		LOCK VALVE FOR GEN SLIDE
		540145		CANNOT GET ALONE, MUST GET 540144
		540162	482972	GEN SLIDE CYLINDER ASSY

		540167		PUMP ONLY FOR THE PUMP/MANIFOLD ASSY 540168 - NO LONGER AVAILABLE - YOU WILL NEED TO REPLACE PUMP/MANIFOLD COMPLETE WITH SPN 533460
		540168	483344	540168 is no longer avail. Direct Replacement is # 3510000076 (SPN 533460).
		540168		PUMP/MANIFOLD ASSY - NO LONGER AVAILABLE - REPLACE WITH SPN 533460
		540170	482708	CYLINDER - POP UP HYD/ GS STEP COVER KIT
		552709		OUTER RAIL
		700003		CONTROL BOARD
		700004	*2*	ISOLATOR RELAY
		800020		HARDWARE KIT
		800170		ROOM MOUNTING KIT
	<u>531129</u>	800174		END CONDITION KIT
		800276	*2*	HARDWARE KIT
	500507	800301	<u>475030</u>	PUMP ONLY
		800327		INSTALL KIT
		800330	512807	recall 05252 dipstick & sticker
		1213190		CLEVIS PIN
		1213460		PIN CLIP
	905898033	905898002		REMOTE/TRANSMITTERS TO OPERATE ELECTRIC KWIKEE SLIDE (TWO TRANSMITTERS)
		<u>1010000015</u>	500324	ASSY- SLIDE-OUT BRACKET KIT
		<u>1010000051</u>	505296	JACK- ELECT LVL15 RH 9K REAR
	9010000051	<u>1010000056</u>	<u>520857</u>	BRACKET, WELD ELECTRIC JACK
		1010000142	514060	9K 13" STROKE RH ASSY ELEC JACK - FRONT
		<u>1010000143</u>	514059	12K 13" STROKE LH ASSY ELEC JACK - REAR

		1010000155 lh/ 501092 rh		THIS IS THE # FOR THE MOTOR ASSY ONLY THAT IS ON THE JACK. MUST DETERMINE IF RIGHT HAND MOTOR OR LEFT HAND MOTOR IS NEEDED. RH MOTOR 1010001019 (SPN 534003) LH MOTOR 1010001018 (SPN 534002)
		<u>1010000258</u>	<u>527949</u>	JACK BRACKET
	<u>524533</u>	<u>1010000803</u>	<u>537058</u>	MOTOR
		1010000848		IS THE 140-1224 CONTROL PLUS TIP SHEET
		<u>1010001018</u>	<u>534002</u>	MOTOR KIT (4 BOLTS, MOTOR, AND TIP SHEET) LEFT HAND MOTOR
		<u>1010001019</u>	<u>534003</u>	MOTOR KIT (4 BOLTS, MOTOR, AND TIP SHEET) RIGHT HAND MOTOR
		1510000006	527395	MOTOR, ULT TQ MX2,DS W/O PIN W/CONN
		1510000014		THIS IS THE # FOR THE MOTOR ASSY ONLY THAT IS ON THE JACK. MUST DETERMINE IF RIGHT HAND MOTOR OR LEFT HAND MOTOR IS NEEDED. RH MOTOR 1010001019 (SPN 534003) LH MOTOR 1010001018 (SPN 534002)
		3010000914		THIS IS THE TIP SHEET THAT GOES WITH THE 140-1224 IN KIT # 1010000848
		3510000076	533460	PUMP & MANIFOLD ASSY
	501102 sub to 500893	030-1040	<u>497545</u>	GROMMETS
	<u>501090</u>	030-1040	<u>497545</u>	PUSH IN GROMMET
		030-1052		O-RINGS
		070-1261		90 DEG FITTING INTO JACK #6SAE TO #4JIC
		070-1267		INLINE FITTING INTO JACK #6SAE TO #4JIC
		070-1269	*1*	90 DEG ELBOW FITTING #4SAE TO #6JIC

		07-1059	<u>333131</u>	90 DEG FITTING INTO JACK #6SAE TO #6JIC
		07-1085	<u>488419</u>	CONNECTOR INLINE #6SAE TO #6JIC
		07-1135		hex plug for 500385th
	501102 sub to 500893	07-1239		HEXAGON PLUG (TO DRAIN) TANK
		080-AA076-ii	466373	HOSE KIT
		080-AA110WS	483341	HOSE FOR HYD G/S STEP CVR INPUT/OUTPUT
		080-AA287-ii	514063	HOSE
		080-AA306-ii	514062	HOSE
		080-AA360ws		HOSE 360"
		090-1166	*4*	PRESSURE SWITCH
	<u>540168</u>	<u>090-1171</u>	<u>527771</u>	MANIFOLD ASSY (W/SOLENOID)
	501189	09-1138		COIL/SOLENOID
		<u>1010001131</u>	<u>538366</u>	LEVELING CONTROL KIT
		130-1146	<u>385165</u>	MOTOR
		130-1149	<u>409218</u>	MOTOR
		130-1161	<u>409218</u>	MOTOR
		130-1165	<u>443174</u>	MOTOR
		130-1189		PUMP MOTOR SOLENOID ASSY (W/ RESERVIOR)
		130-1197	<u>402133</u>	MOTOR
		130-1204	<u>443174</u>	MOTOR
		130-1205	464508	"CENTER DRIVE" MOTOR (W/O PIN)
		130-1205	460831	"RAIL MOUNTED" MOTOR W/PIN
	130-1266	130-1211		RESERVIOR ONLY FOR HYD PUMP ASSY
	501102 sub to 500893	130-1213	507545	BREATHER CAP/ DIPSTICK
	<u>501090</u>	130-1214	527463	FILL PLUG (BREATHER CAP) W/ DIPSTICK
		130-1266	537638	HYDRAULIC PUMP/MOTOR ONLY.
		130-1271	<u>537058</u>	NOW REPLACED BY 101-0000803 MOTOR
		130-2046	<u>443174</u>	MOTOR
		13-1010	<u>507544</u>	IS NOW VPN 500310
		13-1083S	<u>331609</u>	SUBS INTO A 520317S
		13-1086	<u>331609</u>	MOTOR
		13-1089	<u>331609</u>	MOTOR
	500507	13-1099		REPLACEMENT TANK ONLY
		13-1100	248867	PUMP MOTOR ASSY

		13-1104		MOTOR PUMP ASSY
		13-1109	<u>409218</u>	MOTOR
		13-1115	<u>385165</u>	MOTOR
		13-1116	<u>385165</u>	MOTOR
		13-1118	<u>385165</u>	MOTOR
		13-1127		MOTOR
		140-1139		
		140-1144	<u>368510</u>	CURRENT LIMITER SWITCH/ CONTROLLER
		140-1154	407216	CONTROL BOARD/TOUCH PAD
		140-1165	<u>392197</u>	CONTROL BOARD/TOUCH PAD
		140-1175	<u>456939</u>	CONTROLLER/BOX
		<u>140-1176</u>	<u>460713</u>	TEACH PENDANT
		140-1178S	<u>507556</u>	CONTROLLER/BOX
		140-1178S	<u>507556</u>	same as 140-1229 w/ adapter harness
	VTL01A008-2	140-1191	<u>488420</u>	SENSOR LEVEL-FRONT AIR HYDROLIC
		140-1191	<u>488420</u>	SENSOR LEVEL-FRONT AIR HYDROLIC
	VTL01A008-3	140-1192	<u>474690</u>	SENSOR LEVEL -REAR AIR HYDROLIC
		140-1193	<u>512325</u>	MODULE, AIR I/O SENSOR LEVEL 140-1193 (VTL01A006-1)
	501195	140-1195	<u>483348</u>	TOUCH PAD (VTL02A008-1)- MUST ORDER KIT 800283 (comes with harness)
		140-1224	<u>548838</u>	LEVELING CONTROL BOX
	<u>9010000003</u>	140-1226	<u>407218</u>	TOUCH PAD
		140-1226	<u>407218</u>	same as 500629s touch pad w/ harness adap
		140-1227	<u>479221</u>	CONTROL BOX
		140-1227	<u>407219</u>	same as 500630s control box w/ harness ada
		140-1228		Control box, DA
		140-1231	585302	TOUCH PAD
		140-1244	<u>533066</u>	SENSOR FOR ALL ELECTRIC JACK ASSY
	<u>1010000051</u>	140-1244	<u>533066</u>	SENSOR FOR JACK
		141-0004012	*1*	harness for control box # 140-1249.
		141-0018018		HARNESS, SENSOR TO VALVE W/ RESISTOR TERMINATION PLUG

		141-0023012	<u>491552</u>	ADAPTER HARNESS FOR 500675, 500674, 500629, 500630,140-1170,AND 140- 1178
	514796	141-0047200	*1*	HARNESS, (PWR DISTR). JACK TO CONTROL BOARD.
		14-1080	<u>113889</u>	LOCK ASSY
		14-1086	<u>122860</u>	
		14-1089		AUTO RESET BREAKER
		14-1090		AUTO RESET BREAKER
		14-1130	<u>246063</u>	RELAY CONTROL
	<u>140-1163</u>	14-1138	<u>445463</u>	WIRE HARNESS
		14-1138	<u>445463</u>	6-PIN PIGTAIL HARNESS
	<u>523581</u>	150-1480		SET SCREW FOR S/O ASSY
		150-1490	*16*	SCREW 1/4-20 X 1 1/2
		150-1554	<u>547747</u>	SET SCREW-FOR SPN 507555 (SPUR GEAR 250- 0010)
		15-1130		SCREW
		15-1131		NUT, HEX 1/2-13
		15-1341		NUT
		15-1369		screw, hhc 1/4-20x1 7/16
		15-1378		BOLT
		15-1441	*6*	LOCK NUT 1/4-20
		16-1034		FLAT WASHER
		16-1034		WASHER
		18-1007	<u>464963</u>	SHEER PIN
		18-1032	<u>472728</u>	PIN CLIP .125"
		18-1034	535919	PIN - 3/16"x 1 1/2"
	<u>520717</u>	18-1036	<u>467339</u>	ROLL PIN
		18-1037		PIN, GROOVED 1/4 IN. X 1.25
		18-1038		
	<u>522706</u>	18-1039	<u>238957</u>	ROLL PIN
		190-1027		BUSHING
		19-1008		BEARING, THRUST
		250-0001	472725	SPUR GEAR
	<u>524533</u>	250-0010	<u>507555</u>	SPUR GEAR
		260-0003	472726	GEAR SHAFT
		260-0018		GEAR SHAFT
		320-0009	472729	OUTER ROLLER (GOES BY MOTOR)
		320-0015	*3*	ROLLER - SUPPORTS OUTER RAIL
		320-0032		ROLLER

		320-0036		WEDGE STRAP W/KEEPER
		500082HR	073677	
		500105		OBSOLETE - replaced with upgrade kit POWER GEAR # 500643
		500145		ALL 3 THE SAME FOR THIS SYSTEM
		500338S		MANIFOLD ASSY (3 LEG VALVE/COILS)
		500630S	407219	CONTROL BOX ONLY
		500674S	462484	CONTROL BOARD/BOX
		500675S	585302	same as 140-1231 w/ adapter harness
		5013-161		AUXILLARY HARNESS
		5018-072		SAFTEY INTERCONNECT HARNESS
		522709		outer rail assy
		522715		SLIDE ADJUSTER BRKT W/NUT
		522895S	385165	
		523013S	\	MOTOR
		523495		RAIL ASSY COMPLETE
		523529S	463291	MOTOR-MAXITORQUE
		523833		MOTOR
	500507	800036S		REPLACEMENT TANK 13- 1099 W/GASKET
	500082	800129S	407220	SEAL KIT
	500146	800129s	407220	SEAL KIT FOR 500146
	500235	800129S	407220	SEAL KIT
	500814	800129S	407220	SEAL KIT
	500082HR	800129S	407220	SEAL KIT
		800129S	407220	SEAL KITS
		800130S	376085	SEAL KITS
		800131S	376084	SEAL KITS
	500384H	800132S	407239	SEAL KIT
		800132S	407239	SEAL KITS
	500385	800137S	407333	SEAL KIT
	500385th	800137S	407333	SEAL KIT
		800137S	407333	SEAL KITS
	500759	800138s	407335	SEAL KIT
	500932	800138s	407335	SEAL KIT
		800138S	407335	SEAL KITS
	500800	800199S	407336	seal kit for 3510000111
	500800	800199s	407336	SEAL KIT
		800199S	407336	SEAL KITS

		DN12148		BRACKET - S/O VERTICAL ADJ HEAD BRKT
	501095	DN12879		BOLT ONLY FOR FOOT PAD
	501096	DN12879		BOLT ONLY FOR FOOT PAD
	501175	DN12879		BOLT ONLY FOR FOOT PAD
		DN13028		WOODRUFF KEY
		DN13747	445556	SPUR GEAR
		DN14564		RAIL
	F07-9340	K-887		HARNESS, THAT IS FROM JFB MFG CO. - NOT A POWER GEAR PART AT THIS TIME. MAY BE CONNECTED TO THE NEW VALID SYSTEMS
		VTL-02A005-A	<u>464734</u>	CONTROL PANEL (AIR/HYDROLIC)
				VALID UPDATE HARNESS KIT FOR I/O MODULE - THIS IS NOT A POWER GEAR PART, IT IS A JFB MFG PART AND FLTWD SPN # IS 511101. THIS WAS ADDED BY FLTWD AND IS NOT IN THE POWER GEAR PRINTS. 8/2007 AO
	500108			USE # 500507
	500278		303632	USE # 500507
	500409			
	500506			use # 500507
	500507		303632	POWER, UNIT, 4-JACK /POWER GEA
	501102 sub to 500893			
	523766		*5*	MOTOR
	530042			
	<u>540020</u>			

	<u>9010000003</u>		500348	ELECTRICAL JACK SYSTEM - JACKS NOT INCLUDED. TOUCH PAD 140-1226, CONTROL BOX 140-1224, BRACKETS 1010000056, MANUAL, qty 3 HARNESS , NUTS, BOLTS WASHER
	9010000051			ELECTRIC JACK SYSTEM
	500235H			
	<u>500384HR</u>			SEAL KIT
	500385th		224116	SPRINGS NOT AVAILABLE - REPLC COMPLT
	5019-420			AUTOMATIC CONTROL BOX HARNESS 420"
	5020-336			SAFETY INTERCONNECT HARNESS 336"
	5021-542			PUMP HARNESS 542"
	070-1277			compression fitting
	500660S		<u>462133</u>	OBSOLETE- NOW SUBS TO 500643 (SPN 462133)
		1010001289	<u>549107</u>	BRAKE, MOTOR W/BOOT&CLAMP KIT
		1510000125		Y harness only p/o 549107 kit
		260-0004		shaft, keyed .75" X 7.25"
		523440		OUTER RAIL WELD 3X3 75"
		1510000055		SAFETY INTERCONNECT HARNESS

		1010001093	*1*	<p>RH MOTOR ASSY- W/SENSOR FOR NEWER ELECTRIC JACKS.....PLEASE DO NOT USE THIS PART NUMBER....USE 1010001019 OR SPN 534003. THE ONLY DIFFERENCE IS A 2ND WIRE COMING OFF THE MOTOR BUT THIS HARNESS IS NOT USED. VPN 1010001019 IS A KIT THAT CONTAINS THE REPLACEMENT MOTOR/GEARBOX, INSTRUCTIONS, AND MOUNTING BOLTS.</p>
		1010001092	*3*	<p>LH MOTOR ASSY- W/SENSOR FOR NEWER ELECTRIC JACKS.....PLEASE DO NOT USE THIS PART NUMBER....USE 1010001018 OR SPN 534002. THE ONLY DIFFERENCE IS A 2ND WIRE COMING OFF THE MOTOR BUT THIS HARNESS IS NOT USED. VPN 1010001018 IS A KIT THAT CONTAINS THE REPLACEMENT MOTOR/GEARBOX, INSTRUCTIONS, AND MOUNTING BOLTS.</p>
	501059	500199	<u>086594</u>	FLOAT SWITCH FOR PUMP ASSY
		<u>250-0005</u>	<u>550208</u>	SPUR GEAR (IS NOW 3010000400)
				510116 is now DIRECTLY REPLACED BY 140-1144. THE 140-1163 WILL STILL WORK, BUT IT IS NOT NECESSARY TO CHANGE HARNESS SYSTEM WITH THE 140-1144 WILL "PLUG AND PLAY" PER JEFF @ PWR GR 2/12/08

		531077		NYLON SPACER (4 PER SLIDE OUT RAIL)
		531080		NYLON SPACER (4 PER SLIDE OUT RAIL)
		520043		2 pc drive tube assy
		141-0045250		touch pad harness
		5020-258		saftey interconnect harness
		500661		pump harness
	<u>524550</u>			INNER RAIL
		909510000	<u>236643</u>	STEP CONTROL MODULE- Per vendor, use 909506003 (*spn 236643) or 909510003 to replace this control module
		909510001	<u>236643</u>	STEP CONTROL MODULE- Per vendor, use 909506003 (*spn 236643) or 909510003 to replace this control module
		909342000		step repair kit
		530035		GEAR 2" 530035
		530025		GEAR 2.5" 530025
		530030		SHAFT SING MASTER - 530030
		530014		DRIVE SHAFT ASSM. 530014
		15-1433		SCREW
		19-1015		ROLLER BEARING
		16-1059		FLAT WASHER
B50-0400	<u>531097</u>	15-1348	568558	LOCK NUT
		15-1439		SCREW
		15-1437		LOCK NUT W/WELD
		522261		base plate assy
		<u>800343</u>	<u>467341</u>	KIT CONTAINS 3 SENSORS (140-1189 SPN 534006) , 3 O-RINGS, & 9 SCREWS-AO